

ZEPHYR OEM

Immersed electrode humidifiers for air handling units



WARNING

Make sure you read and fully understand the manual before using this device.

Non-observance of these instructions may result in death or serious injury.



CONTENTS

| | |
|---|-----------|
| IMPORTANT INFORMATION | 6 |
| IMPORTANT SAFETY INFORMATION | 7 |
| SAFETY INFORMATION RELATING TO THE PRODUCT | 8 |
| SAFETY INFORMATION RELATED TO HEALTH AND HYGIENE | 9 |
| 1. INTRODUCTION | 10 |
| 1.1 Description | 10 |
| 1.2 Product overview | 10 |
| 1.3 Main features | 11 |
| 1.3.1 Electronic control features | 11 |
| 1.4 Applications | 11 |
| 1.5 Available configurations | 12 |
| 1.5.1 ExtraSmall models | 12 |
| 1.5.2 Small models | 12 |
| 1.5.3 Medium models | 12 |
| 1.5.4 Large models | 12 |
| 1.6 Accessories | 13 |
| 1.6.1 Linear distributors | 13 |
| 1.6.2 Boilers | 13 |
| 1.6.3 Sensors and control accessories | 14 |
| 1.6.4 Plumbing components | 14 |
| 1.7 Steam distributor/humidifier configuration table | 14 |
| 2. TECHNICAL DATA | 15 |
| 2.1 Technical specifications | 15 |
| 2.1.1 ExtraSmall models Zephyr OEM | 15 |
| 2.1.2 Small models Zephyr OEM | 16 |
| 2.1.3 Medium models Zephyr OEM | 17 |
| 2.1.4 Large models Zephyr OEM | 18 |
| 3. RECEIVING THE PRODUCT | 19 |
| 3.1 Checking the packaging | 19 |
| 3.1.1 Opening the packaging | 19 |
| 3.1.2 Checking the packaging contents | 19 |
| 4. DIMENSIONS AND MECHANICAL ASSEMBLY | 20 |
| 4.1 Dimensions | 20 |
| 4.1.1 Hydraulic unit | 20 |
| 4.2 Zephyr OEM kit | 21 |
| 4.2.1 Installation hole spacing | 22 |
| 5. INSTALLING THE PLUMBING | 23 |
| 5.1 Before you start | 23 |
| 5.2 Hydraulic unit structure | 23 |
| 5.3 Installing the plumbing | 24 |



CONTENTS

| | |
|---|-----------|
| 5.3.1 Inlet water specifications | 24 |
| 5.4 Water drainage system | 25 |
| 5.4.1 Outlet connection specifications | 25 |
| 5.5 Steam distribution | 26 |
| 6. ELECTRICAL CONNECTIONS | 27 |
| 6.1 Before you start | 27 |
| 6.2 Connection best practice | 27 |
| 6.2.1 Wiring best practices | 27 |
| 6.3 Dimensioning electrical components | 28 |
| 6.4 Electrical connections | 29 |
| 6.4.1 Control board | 29 |
| 6.4.2 Power supply and earth wiring connection | 30 |
| 6.5 Configurations | 31 |
| 6.5.1 ON/OFF connection with humidistat or external contact (CFG = 0-1) | 31 |
| 6.5.2 External proportional humidistat connection (CFG = PROP) | 31 |
| 6.5.3 Humidity sensor connection (CFG = HUM) | 31 |
| 6.5.4 EVHTP520 humidity sensor connection (CFG = HUM and CFG = HUML) | 32 |
| 6.5.5 Connection for humidity sensor and limit sensor (CFG = HUML) | 32 |
| 6.5.6 Humidity sensor connection 0...5 V / 0...10 V | 32 |
| 6.5.7 Temperature sensor connection (CFG = 1T) | 33 |
| 6.5.8 Connection for two temperature sensors (CFG = 2T) | 33 |
| 6.6 DIP switch functions | 33 |
| 6.6.1 DIP switch Control board | 33 |
| 6.6.2 DIP switch Expansion | 33 |
| 7. USER INTERFACE (OPTIONAL) | 34 |
| 7.1 User interface | 34 |
| 7.1.1 Icons | 34 |
| 7.1.2 Keys | 34 |
| 7.1.3 First start-up | 35 |
| 7.2 User interface menu | 35 |
| 7.2.1 Home screen | 35 |
| 7.2.2 Changing the main sensor humidity setpoint | 36 |
| 7.2.3 Changing the temperature setpoint | 36 |
| 7.2.4 Manual draining | 36 |
| 7.2.5 Menu | 37 |
| 7.2.6 User Menu | 38 |
| 7.2.7 Maintenance menu | 39 |
| 7.2.8 Displaying/resetting the operating hours | 40 |
| 7.2.9 Output functional test | 41 |
| 8. POWER-UP AND START-UP | 42 |
| 8.1 First start-up instructions | 42 |



CONTENTS

| | | |
|--------|---|-----------|
| 8.2 | Instructions for seasonal or long-term shut-down..... | 42 |
| 8.3 | Starting up after a seasonal or long-term shut-down | 43 |
| 9. | OPERATION | 44 |
| 9.1 | Principle of operation | 44 |
| 9.2 | Humidity regulation | 44 |
| 9.2.1 | ON-OFF regulation CFG = 0-1 | 44 |
| 9.2.2 | Proportional regulation CFG = PROP..... | 44 |
| 9.2.3 | Regulation with the humidity sensor CFG = HUM | 45 |
| 9.2.4 | Regulation with the humidity sensor + limit sensor CFG = HUML | 46 |
| 9.2.5 | Regulation with a temperature probe CFG = 1T | 47 |
| 9.2.6 | Regulation with two temperature probes CFG = 2T..... | 47 |
| 9.3 | Water dilution | 47 |
| 9.3.1 | Current-based water dilution | 47 |
| 9.3.2 | Time-based water dilution | 48 |
| 9.4 | Hydraulic unit draining | 48 |
| 9.5 | Complete hydraulic unit emptying | 48 |
| 9.6 | Level sensor | 48 |
| 9.7 | Foam management | 48 |
| 9.8 | Operating hours | 49 |
| 9.8.1 | Resetting the operating hours | 49 |
| 9.9 | Overproduction | 49 |
| 10. | CONFIGURATION PARAMETERS | 50 |
| 9.10 | Table of adjustment parameters | 50 |
| 11. | MODBUS RTU FUNCTIONS AND RESOURCES | 53 |
| 11.1 | Introduction..... | 53 |
| 11.2 | Modbus message structure | 53 |
| 11.3 | Modbus functions and registers | 53 |
| 11.3.1 | Available Modbus commands and data areas | 54 |
| 11.4 | Address configuration | 54 |
| 11.5 | Connections | 54 |
| 11.6 | Modbus table content..... | 54 |
| 11.7 | Modbus addresses | 55 |
| 11.7.1 | Modbus address table..... | 55 |
| 11.7.2 | Modbus resource table..... | 58 |
| 12. | DIAGNOSTICS..... | 61 |
| 12.1 | Zephyr OEM alarms table..... | 61 |
| 13. | MAINTENANCE | 66 |
| 13.1 | Before you start | 66 |
| 13.2 | Introduction to maintenance | 66 |



CONTENTS

| | | |
|--|---|-----------|
| 13.3 | Checking the status of the humidifier | 67 |
| 13.4 | Cleaning the boiler | 68 |
| 13.5 | Replacing the boiler | 69 |
| 13.5.1 | Tightening torque for electrode connections | 69 |
| 13.6 | Fitting the boiler | 70 |
| 13.7 | Cleaning/replacing the electrodes | 70 |
| 14. SPARE PARTS | | 71 |
| 14.1 | Hydraulic unit | 71 |
| 14.2 | Electrical part..... | 73 |
| 15. WIRING DIAGRAMS..... | | 74 |
| 15.1 | Wiring diagram for 230 Vac models | 74 |
| 15.2 | Wiring diagram for 400/460 Vac 3Ph models..... | 75 |
| 16. SELECTING AND DEFINING THE MODEL..... | | 76 |
| 16.1 | Introduction..... | 76 |
| 16.2 | Procedure for selecting and defining the model | 76 |

IMPORTANT INFORMATION

Liability and residual risks

ELSTEAM assumes no liability for any damage caused by the following (by way of example; this is not an exhaustive list):

- Installation/use for purposes other than those specified and, in particular, not adhering to the safety provisions set out by current regulations in the country in which the product is installed and/or contained in this manual;
- Use in appliances that do not guarantee sufficient protection against electric shocks, water and dust within the installation conditions created;
- Use in appliances that allow access to hazardous parts without the use of a keyed or tooled locking mechanism when accessing the instrument;
- Tampering and/or modifying the product;
- Installation/use in appliances which do not comply with current regulations in the country in which the product is installed.

The customer/manufacturer is responsible for ensuring their machine complies with these regulations.

ELSTEAM's responsibility is limited to the correct and professional use of the product in accordance with regulations and the instructions contained in this manual and other product support documents.

To comply with EMC standards, observe all the electrical connection instructions. As it depends on the wiring configuration as well as the load and the installation type, compliance must be verified for the final machine as specified by the relevant product standard.

Disclaimer

This document is the exclusive property of ELSTEAM. It contains a general description and/or a description of the technical specifications for the services offered by the products listed herein. This document should not be used to determine the suitability or reliability of these products in relation to specific user applications. Each user or integration specialist should conduct their own complete and appropriate risk analysis, in addition to carrying out a product evaluation and test in relation to its specific application or use. Users can send us comments and suggestions on how to improve or correct this publication.

Neither ELSTEAM nor any of its associates or subsidiaries shall be held responsible or liable for improper use of the information contained herein.

ELSTEAM has a policy of continuous development; therefore, ELSTEAM reserves the right to make changes and improvements to any product described in this document without prior notice.

The images in this document and other documentation supplied with the product are provided for illustrative purposes only and may differ from the product itself.

The technical data in this manual is subject to change without prior notice.

Terms and Conditions of use

Permitted use

The device should only be used for humidification inside the air handling unit (AHU).

The device must be installed and used in accordance with the instructions provided and, in particular, hazardous live parts or highly pressurised water must not be accessible under normal conditions.

The device must be suitably protected from water and dust with regard to its application and must also only be accessible with the aid of a tool.

Only qualified personnel may install the product or perform technical support procedures on it.

The customer must only use the product as described in the documentation relating to that product.

Prohibited use

Any use other than those described in the "**Permitted use**" section and in the product support documentation is prohibited.

Disposal



The device must be disposed of in accordance with local regulations regarding the collection of electrical and electronic appliances.

Consider the environment



The company works towards protecting the environment, while taking account of customer requirements, technological innovations in materials and the expectations of the community to which we belong. ELSTEAM places great importance on respecting the environment, encouraging all associates to become involved with company values and guaranteeing safe, healthy and functional working conditions and workplaces.

Please consider the environment before printing this document.

IMPORTANT SAFETY INFORMATION

Please read this document carefully before installation; study all the warnings before using the device. Only use the device in accordance with the methods described in this document. The following safety messages may be repeated several times in the document, to provide information regarding potential hazards or to attract attention to information which may be useful in explaining or clarifying a procedure.

SYMBOLS



This symbol is used to indicate a risk of electric shock. It is a safety indication and as such, should be observed to avoid potential accidents or fatalities.



This symbol is used to indicate a risk of serious personal injury. It is a safety indication and as such, should be observed to avoid potential accidents or fatalities.



This symbol is used to indicate a serious risk of exposure to biological agents. It is a safety indication and as such, should be observed to avoid potential accidents or fatalities.



This symbol is used to indicate a serious risk of scalding from steam. It is a safety indication and as such, should be observed to avoid potential accidents or fatalities.



This symbol is used to indicate a risk of serious burns. It is a safety indication and as such, should be observed to avoid potential accidents or fatalities.

SAFETY MESSAGES

DANGER

DANGER indicates a situation of imminent danger which, if not avoided, **will lead to death or serious injury**.

WARNING

WARNING indicates a situation of imminent danger which, if not avoided, **may lead to death or serious injury**.

WARNING

WARNING indicates a situation of imminent danger which, if not avoided, **may lead to death or serious injury**.

CAUTION

CAUTION indicates a potentially hazardous situation which, if not avoided, **could cause minor or moderate injury**.

NOTICE

NOTICE indicates a situation not related to physical injuries but which, if not avoided, **could damage the equipment**.

NOTE: the maintenance, repair, installation and use of the equipment must only be entrusted to qualified personnel.

QUALIFIED PERSONNEL

Only suitably trained and experienced personnel capable of understanding the content of this manual and all documentation regarding the product are authorised to work on and with this equipment. Furthermore, the personnel must have completed courses in safety and must be able to recognise and prevent the implied dangers. The personnel must have suitable training, knowledge and experience at a technical level, and be capable of anticipating and detecting potential risks caused by using the product, as well as changing the settings and modifying the mechanical, electric and electronic equipment for the entire system in which the product is used. All personnel working on and with the product must be entirely familiar with the relevant standards and directives, as well as safety regulations.

UNAUTHORISED PERSONNEL

The humidifier must **not** be used by persons (including children) with reduced physical, sensory or mental capabilities or persons with no experience or knowledge.

SAFETY INFORMATION RELATING TO THE PRODUCT

ZEPHYR OEM series humidifiers are defined as "NOT ACCESSIBLE TO THE PUBLIC".

Before carrying out any work on the equipment, read these instructions carefully, making sure you understand everything.

DANGER

RISK OF ELECTRIC SHOCK, EXPLOSION OR ELECTRIC ARC

- Only use electrically insulated measuring devices and equipment.
- Do not install the equipment while the power supply is connected.
- Cut off the power supply to all equipment, including any connected devices, before installing/uninstalling accessories, hardware, cables or wires.
- Provide safety interlocks (isolators) of a suitable size between the power supply and the humidifier, with a contact opening distance of at least 3 mm for each pole.
- Always use a properly calibrated Voltmeter to make sure the system is powered off.
- The maintenance, repair, installation and use of the equipment must only be entrusted to qualified personnel.
- Do not touch the unshielded components or the terminals while they are live.
- Do not open, disassemble, repair or modify the product.
- Do not expose the equipment to liquids or chemicals.
- Make sure there is an effective earth connection.
- Before applying voltage to the equipment:
 - Make sure all protective elements, such as covers, hatches and grilles, are fitted and/or closed using a tool (e.g. a spanner).
- Check all wiring connections.

DANGER

LOOSE WIRING CAUSES ELECTRIC SHOCKS AND OVERHEATING

Tighten the connections in compliance with the technical specifications relating to tightening torques.

DANGER

RISK OF ELECTRIC SHOCK AND FIRE

- Do not use the device with loads greater than those indicated in the technical data section.
- Do not exceed the temperature and humidity ranges indicated in the technical data section.
- Provide safety interlocks (isolators) of a suitable size between the power supply and the humidifier.
- Only use cables with a suitable cross-section as indicated in the section "Wiring best practices".

WARNING

MALFUNCTIONING OF THE EQUIPMENT

- Perform the wiring carefully, in compliance with electromagnetic compatibility and safety requirements.
- Carry out a full start-up test.
- Make sure the wiring is correct for the end application.
- Minimise the length of the connections as much as possible, to avoid winding the cables around electrically connected parts.
- Before applying the power supply, check all the wiring connections.
- Do not connect wires to unused terminals and/or terminals marked with the text "No connection" ("N.C.").

The humidifier produces steam at 100 °C (212 °F) and discharges water at a temperature of approximately 98 °C (208.4 °F).

WARNING

HOT WATER VAPOUR

Do not touch the equipment while it is running.

WARNING

RISK OF BURNS

Before carrying out any work on the system, place the equipment out of service and wait for the machine to cool down (< 50 °C (122 °F)).

WARNING

REGULATORY INCOMPATIBILITY

Make sure all the equipment used and systems designed conform to current local, regional and national standards.

SAFETY INFORMATION RELATED TO HEALTH AND HYGIENE

The **Zephyr OEM** humidifier features:

- Automatic draining for inactivity;
- Periodic automatic cleaning;
- Plastic material on whose surface bacterial colonies do not proliferate.

Inadequate use and/or poor maintenance of the humidifier can damage your health.



BIOLOGICAL RISK

- In the event of poor maintenance/cleaning after the humidifier has been shut-down for a long time, microorganisms (including the bacteria that cause Legionellosis) may proliferate and be transferred into the air treatment system.
- The humidifier must be used correctly and be maintained and cleaned properly at the prescribed intervals, as described in the **MAINTENANCE** chapter.

Thoroughly remove limescale and biofilm residues from the reservoir and drain (rinse the inside of the reservoir with 20% citric acid and appropriate biocides, and clean the limescale off the surface).

1. INTRODUCTION

1.1 Description

The **Zephyr OEM** humidifier is the ELSTEAM solution for immersed electrode humidifier systems dedicated to PAC/CLOSE CONTROL applications and to all applications that require small kits to install the electrical part for remote management of the hydraulic part.

The **Zephyr OEM** humidifier consists of 4 elements:

- Hydraulic unit;
- Wiring kit (to be purchased separately);
- Electronic controller on DIN rail mount (to be purchased separately);
- TA current sensor.

It can all be equipped with an LED HMI interface and other accessories (see chapter "**1.6 ACCESSORIES**" ON PAGE 13)

Zephyr series humidifiers generate humidity (steam) by means of a current passing between 2 or 3 electrodes immersed in drinking water to bring it to boiling point.

The steam is controlled by adjusting the intensity of the current transferred to the water by the immersed electrodes, which indirectly controls the boiling of the water.

The steam is introduced into the air handling unit by means of a steam hose and a linear distributor, after placing the OEM kit inside the compartment provided by the manufacturer.

The **Zephyr OEM** humidifier is inserted into the compartment provided, which is NOT ACCESSIBLE to the public, not exposed to the weather and therefore protected. To prevent ice from forming during winter if the unit is installed outside, use heating cables for the water supply and outlet pipes.

NOTE: **Zephyr OEM** series humidifiers are defined as "**NOT ACCESSIBLE TO THE PUBLIC**".

1.2 Product overview




Fig. 1. Hydraulic unit overview

| Reference | Description | Reference | Description |
|-----------|-----------------------------------|-----------|--|
| ① | Boiler | ⑤ | Water outlet and overflow circuit |
| ② | Electric outlet pump | ⑥ | Water filling reservoir |
| ③ | Inlet solenoid valve | ⑦ | Water outlet pipe (32 mm (1.26 in.) or 40 mm (1.57 in.)) |
| ④ | Water filling fitting, 3/4" M GAS | ⑧ | Steam outlet |

1.3 Main features

- Isothermal humidifier;
- Sterile steam (steam with a temperature of approximately 100 °C (212 °F));
- Automatic boiler cleaning;
- Cleanable and reusable fire-retardant boiler;
- Operating algorithm optimises energy and water efficiency;
- Broad range of steam production (2...40 kg/h);
- Built-in electronic control;
- Stainless steel water drain tray on request.

1.3.1 Electronic control features

- Proportional control of steam production:
 - High efficiency;
 - Rapid response to changes in requirements;
 - Production control.
- Electrode and boiler cleaning system:
 - Reduced maintenance frequency;
 - High performance levels;
 - Longer electrode and boiler life.
- Automatic or manual boiler draining:
 - Longer boiler life.
- Smart user interface indicates operating status (with display connected only):
 - Continuous monitoring of the operating status;
 - Automatic fault analysis;
 - Advanced error diagnostics;
 - Operating time counter.
- Remote supervision with EPoCA (optional via **EVIF25** interface).

1.4 Applications

The **Zephyr OEM** series is mainly used in applications requiring sterile steam, including:

- Data centres;
- Industrial plants;
- Offices;
- Civil settings;
- Home MEV settings;
- Call centres;
- Hotels;
- Museums and libraries;
- Technological or medical settings;
- Tobacco industry;
- Food industry;
- Maturing;
- Wood industry;
- Paper mills;
- Printing industries;
- Turkish baths.

1.5 Available configurations

1.5.1 ExtraSmall models

| P/N | Description | Configuration |
|--------------------|---|---|
| EHK00000XS | Zephyr OEM XS immersed electrode humidifier without boiler | ExtraSmall kit, without boiler |
| EHK0002M0XS | Zephyr OEM immersed electrode humidifier, 2 kg/h, 400/460 Vac | ExtraSmall kit, 2 kg/h, 230 Vac, single-phase |
| EHK0003T0XS | Zephyr OEM immersed electrode humidifier, 3 kg/h, 400/460 Vac | ExtraSmall kit, 3 kg/h, 400 Vac, three-phase |
| EHK0003T0XS | Zephyr OEM immersed electrode humidifier, 3 kg/h, 400/460 Vac | ExtraSmall kit, 3 kg/h, 460 Vac, three-phase |

1.5.2 Small models

| P/N | Description | Configuration |
|-------------------|---|--|
| EHK000000S | Zephyr OEM S immersed electrode humidifier without boiler | Small kit, without boiler |
| EHK0003M0S | Zephyr OEM S immersed electrode humidifier, 3 kg/h, 230 Vac | Small kit, 3 kg/h, 230 Vac, single-phase |
| EHK0008T0S | Zephyr OEM S immersed electrode humidifier, 5–8 kg/h, 400/460 Vac | Small kit, 5 kg/h, 400 Vac, three-phase |
| EHK0008T0S | Zephyr OEM S immersed electrode humidifier, 5–8 kg/h, 400/460 Vac | Small kit, 5 kg/h, 460 Vac, three-phase |
| EHK0008T0S | Zephyr OEM S immersed electrode humidifier, 5–8 kg/h, 400/460 Vac | Small kit, 8 kg/h, 400 Vac, three-phase |
| EHK0008T0S | Zephyr OEM S immersed electrode humidifier, 5–8 kg/h, 400/460 Vac | Small kit, 8 kg/h, 460 Vac, three-phase |

1.5.3 Medium models

| P/N | Description | Configuration |
|-------------------|---|---|
| EHK000000M | Zephyr OEM M immersed electrode humidifier without boiler | Medium kit, without boiler |
| EHK0005M0M | Zephyr OEM M immersed electrode humidifier, 5 kg/h, 400/460 Vac | Medium kit, 5 kg/h, 230 Vac, single-phase |
| EHK0015T0M | Zephyr OEM M immersed electrode humidifier, 10–15 kg/h, 400/460 Vac | Medium kit, 10 kg/h, 400 Vac, three-phase |
| EHK0015T0M | Zephyr OEM M immersed electrode humidifier, 10–15 kg/h, 400/460 Vac | Medium kit, 10 kg/h, 460 Vac, three-phase |
| EHK0015T0M | Zephyr OEM M immersed electrode humidifier, 10–15 kg/h, 400/460 Vac | Medium kit, 15 kg/h, 400 Vac, three-phase |
| EHK0015T0M | Zephyr OEM M immersed electrode humidifier, 10–15 kg/h, 400/460 Vac | Medium kit, 15 kg/h, 460 Vac, three-phase |

1.5.4 Large models

| P/N | Description | Configuration |
|-------------------|---|--|
| EHK000000L | Zephyr OEM L immersed electrode humidifier without boiler | Large kit, without boiler |
| EHK0040T0L | Zephyr OEM L immersed electrode humidifier, 20–40 kg/h, 400/460 Vac | Large kit, 20 kg/h, 400 Vac, three-phase |
| EHK0040T0L | Zephyr OEM L immersed electrode humidifier, 20–40 kg/h, 400/460 Vac | Large kit, 20 kg/h, 460 Vac, three-phase |
| EHK0040T0L | Zephyr OEM L immersed electrode humidifier, 20–40 kg/h, 400/460 Vac | Large kit, 30 kg/h, 400 Vac, three-phase |
| EHK0040T0L | Zephyr OEM L immersed electrode humidifier, 20–40 kg/h, 400/460 Vac | Large kit, 30 kg/h, 460 Vac, three-phase |
| EHK0040T0L | Zephyr OEM L immersed electrode humidifier, 20–40 kg/h, 400/460 Vac | Large kit, 40 kg/h, 400 Vac, three-phase |
| EHK0040T0L | Zephyr OEM L immersed electrode humidifier, 20–40 kg/h, 400/460 Vac | Large kit, 40 kg/h, 460 Vac, three-phase |

1.6 Accessories

The following accessories are available for use with **Zephyr OEM** series immersed electrode humidifiers:

1.6.1 Linear distributors

| P/n | Description |
|------------------|---|
| EHSD040T | Linear steam distributor, 400 mm (1.31 ft). |
| EHSD060T | Linear steam distributor, 600 mm (1.97 ft). |
| EHSD080T | Linear steam distributor, 800 mm (2.62 ft). |
| EHSD100T | Linear steam distributor, 1000 mm (3.28 ft). |
| EHSD130T | Linear steam distributor, 1300 mm (4.26 ft). |
| EHSDP000T | Custom linear steam distributor. |
| EHSD040X | Linear steam distributor with high thermal efficiency, 400 mm (1.31 ft). |
| EHSD060X | Linear steam distributor with high thermal efficiency, 600 mm (1.97 ft). |
| EHSD080X | Linear steam distributor with high thermal efficiency, 800 mm (2.62 ft). |
| EHSD100X | Linear steam distributor with high thermal efficiency, 1000 mm (3.28 ft). |
| EHSD130X | Linear steam distributor with high thermal efficiency, 1300 mm (4.26 ft). |
| EHSDP000X | Custom steam distributor with high thermal efficiency. |
| EHSDW022 | Steam distributor with 22 mm (0.87 in.) nozzle. |
| EHSDC038 | 90° steam distribution connection, Ø38 mm (1.50 in.). |

1.6.2 Boilers

| P/n | Description |
|--------------------|--|
| EBK002M00XS | Cleanable boiler for ExtraSmall standard, 2 kg/h, single-phase models |
| EBK002MHCS | Cleanable boiler for ExtraSmall high-conductivity, 2 kg/h, single-phase models |
| EBK002MLCS | Cleanable boiler for ExtraSmall low-conductivity, 2 kg/h, single-phase models |
| EBK003M00S | Cleanable boiler for Small standard, 3 kg/h, single-phase models |
| EBK003MHCS | Cleanable boiler for Small high-conductivity, 3 kg/h, single-phase models |
| EBK003MLCS | Cleanable boiler for Small low-conductivity, 3 kg/h, single-phase models |
| EBK003T00XS | Cleanable boiler for ExtraSmall standard, 3 kg/h, three-phase models |
| EBK003THCS | Cleanable boiler for ExtraSmall high-conductivity, 3 kg/h, three-phase models |
| EBK003TLCS | Cleanable boiler for ExtraSmall low-conductivity, 3 kg/h, three-phase models |
| EBK005M00M | Cleanable boiler for Medium standard, 3–5 kg/h, single-phase models |
| EBK005MHCM | Cleanable boiler for Medium high-conductivity, 3–5 kg/h, single-phase models |
| EBK005MLCM | Cleanable boiler for Medium low-conductivity, 3–5 kg/h, single-phase models |
| EBK005T00S | Cleanable boiler for Small standard, 5–8 kg/h, three-phase models |
| EBK005THCS | Cleanable boiler for Small high-conductivity, 5–8 kg/h, three-phase models |
| EBK005TLCS | Cleanable boiler for Small low-conductivity, 5–8 kg/h, three-phase models |
| EBK015T00M | Cleanable boiler for standard, 10–15 kg/h, three-phase models |
| EBK015THCM | Cleanable boiler for high-conductivity, 10–15 kg/h, three-phase models |
| EBK015TLCM | Cleanable boiler for low-conductivity, 10–15 kg/h, three-phase models |
| EBK040T00L | Cleanable boiler for standard, 20–30–40 kg/h, three-phase models |
| EBK040THCL | Cleanable boiler for high-conductivity, 20–30–40 kg/h, three-phase models |
| EBK040TLCL | Cleanable boiler for low-conductivity, 20–30–40 kg/h, three-phase models |

1.6.3 Sensors and control accessories

| P/n | Description |
|-----------------------|---|
| EVIF25TW4X0001 | EVLINK TTL/Wi-Fi + RTC 12-30VDC |
| EV3411M7 | 1-output electronic controller, 230 VAC power supply, 1 multi-sensor analogue input. |
| EVHTP520 | Temperature/humidity sensor with 5...95% r.H. and -10...70 °C range. |
| EVHP523 | 4...20 mA humidity transducer with 5...95% r.H. range. |
| EVHTP523 | Humidity and temperature transducer, 8...28 VDC power supply, 2 x 4...20 mA output signals. |
| EVTNW30F200 | NTC sensor, 3 m long 2-wire thermoplastic cable, 5x20 mm comoulded bulb, IP68 protection. |

1.6.4 Plumbing components

| P/n | Description |
|-------------------|--|
| 0031000048 | 3/4" GAS female hose to connect the water mains to the water inlet solenoid valve, 300 mm (11.81in.) |
| EHTV038 | Steam pipe, Ø38 mm (1.50 in.) |
| EHTC010 | Condensate outlet pipe, Ø10 mm |
| EHFILLTANK | Low/high pressure tank filling kit |

1.7 Steam distributor/humidifier configuration table

| Steam distributor | EHKO humidifiers | | | | | | | | |
|-------------------|---|---------|---------|---------|------------------|-------------------|-------------------|--------------------|--------------------|
| | EHKO002 | EHKO003 | EHKO005 | EHKO008 | EHKO010 | EHKO015 | EHKO020 | EHKO030 | EHKO040 |
| EHSD040• | X | X | X | X | X ^(*) | --- | --- | --- | --- |
| EHSD060• | X | X | X | X | X | X ^(**) | X ^(**) | --- | X ^(**) |
| EHSD080• | X | X | X | X | X | X | X | X ^(***) | X ^(***) |
| EHSD100• | --- | --- | --- | --- | X | X | X | X | X |
| EHSD130• | --- | --- | --- | --- | X | X | X | X | X |
| EHSDY038 | Can be used to double the steam output and for small steam emission ducts with short steam distributors | | | | | | | | |
| EHSDC038 | X | X | X | X | X | X | X | X | X |
| EHSDW022 | X | X | X | X | X | X | X | X | X |

NOTE: The • symbol indicates that the data applies to every p/n (X/T); contact the ELSTEAM sales office for further information.

(*) = Use 2 **EHSD040•** + 1 **EHSDY038** manifold

(**) = Use 2 **EHSD060•** + 1 **EHSDY038** manifold

(***) = Use 2 **EHSD080•** + 1 **EHSDY038** manifold

(#) = Use 4 **EHSD080•** + 2 **EHSDY038** manifolds

(##) = Use 4 **EHSD100•** + 2 **EHSDY038** manifolds

(###) = Use 2 **EHSR015M2** + 1 **EHSDY038** manifold

2. TECHNICAL DATA

2.1 Technical specifications

2.1.1 ExtraSmall models | Zephyr OEM...

| Description | MU | EHK00000XS | EHK0002M0XS | EHK0003T0XS |
|---|------------|--|-------------|-------------------------------|
| Steam production | | | | |
| Production capacity: | kg/h | 2...3 | 2 | 3 |
| Pressure limits: | Pa/bar | 500/0.005 | | |
| Steam connection diameter: | mm (in.) | 38 (1.50) | | |
| Electrical properties | | | | |
| Power absorbed: | kW | 1.5...2.2 | 1.5 | 2.25 |
| Power supply: | V | Configurable 230/400/460 Vac | 230 Vac | Configurable 400 / 460 Vac |
| Frequency: | Hz | 50/60 | | |
| Phases: | Ph | Configurable | 1 | 3 |
| Absorption per phase: | A | Configurable | 6.4 | 3.2 / 2.8 |
| Water properties | | | | |
| Supply water quality: | --- | See section " 5.3.1 INLET WATER SPECIFICATIONS " ON PAGE 24 | | |
| Supply water conductivity: | μS*cm | 70...1250 | | |
| Supply water hardness: | °f | 5...50 | | |
| Minimum inlet flow rate: | l/h | 300 | | |
| Supply water pressure: | MPa/bar | 0.02...1/0.2...10 | | |
| Water inlet connection: | --- | M 3/4" GAS | | |
| Water outlet outside diameter: | mm (in.) | 32 (1.26) | | |
| General specifications | | | | |
| Dimensions: | mm (in.) | See section " 4.1 DIMENSIONS " ON PAGE 20 | | |
| IP protection degree of the hydraulic unit: | --- | IPX0 | | |
| Maximum installation altitude: | m (ft.) | ≤2000 (6561.6) | | |
| Ambient conditions of the hydraulic unit | | | | |
| Ambient operating conditions: | °C (°F), % | 1...40 (33.8...104), 10...80% | | |
| Transportation and storage conditions: | °C (°F), % | -10...70 (14...185), 5...95% | | |
| Regulation | | | | |
| Control type/command signal: | --- | ON/OFF Proportional Probe | | |
| Supervision/Configuration: | --- | RS-485 MODBUS Supervision Wi-Fi | | |
| Compliance | | | | |
| EC: | --- | Yes, with self-certification | | |

NOTE: Models with dual hydraulic units can be created by adding an expansion to the control board, in which case the aforementioned values become the sum of those for the 2 hydraulic units chosen.

2.1.2 Small models | Zephyr OEM...

| Description | MU | EHK00000S | EHK0003M0S | EHK0005T0S | EHK0008T0S |
|---|------------|--|------------|-------------------------------|-----------------------------------|
| Steam production | | | | | |
| Production capacity: | kg/h | 3...8 | 3 | 5 | 8 |
| Pressure limits: | Pa/bar | 500/0.005 | | | |
| Steam connection diameter: | mm (in.) | 22 (0.87) | | | |
| Electrical properties | | | | | |
| Power absorbed: | kW | 2.2...6 | 2.2 | 3.75 | 6 |
| Power supply: | V | Configurable 230/400/460 Vac | 230 Vac | Configurable 400 / 460 Vac | Configurable 400 Vac / 460 Vac |
| Frequency: | Hz | 50/60 | | | |
| Phases: | Ph | Configurable | 1 | 3 | |
| Absorption per phase: | A | Configurable | 9.6 | 5.4 / 4.7 | 8.6 / 7.5 |
| Water properties | | | | | |
| Supply water quality: | --- | See section "5.3.1 INLET WATER SPECIFICATIONS" ON PAGE 24 | | | |
| Supply water conductivity: | μS*cm | 70...1250 | | | |
| Supply water hardness: | °f | 5...50 | | | |
| Minimum inlet flow rate: | l/h | 300 | | | |
| Supply water pressure: | MPa/bar | 0.02...1/0.2...10 | | | |
| Water inlet connection: | --- | M 3/4" GAS | | | |
| Water outlet outside diameter: | mm (in.) | 32 (1.26) | | | |
| General specifications | | | | | |
| Dimensions: | mm (in.) | See section "4.1 DIMENSIONS" ON PAGE 20 | | | |
| IP protection degree of the hydraulic unit: | --- | IPX0 | | | |
| Maximum installation altitude: | m (ft.) | ≤2000 (6561.6) | | | |
| Ambient conditions of the hydraulic unit | | | | | |
| Ambient operating conditions: | °C (°F), % | 1...40 (33.8...104), 10...80% | | | |
| Transportation and storage conditions: | °C (°F), % | -10...70 (14...185), 5...95% | | | |
| Regulation | | | | | |
| Control type/command signal: | --- | ON/OFF Proportional Probe | | | |
| Supervision/Configuration: | --- | RS-485 MODBUS Supervision Wi-Fi | | | |
| Compliance | | | | | |
| EC: | --- | Yes, with self-certification | | | |

NOTE: Models with dual hydraulic units can be created by adding an expansion to the control board, in which case the aforementioned values become the sum of those for the 2 hydraulic units chosen.

2.1.3 Medium models | Zephyr OEM...

| Description | MU | EHK000000M | EHK0005M0M | EHK0015T0M |
|---|------------|--|------------|-----------------------------|
| Steam production | | | | |
| Production capacity: | kg/h | 5...15 | 5 | 10...15 |
| Pressure limits: | Pa/bar | 500/0.005 | | |
| Steam connection diameter: | mm (in.) | 38 (1.50) | | |
| Electrical properties | | | | |
| Power absorbed: | kW | 3.75...11.5 | 3.75 | 7.5 / 11.5 |
| Power supply: | V | Configurable 400/460 Vac | 230 Vac | Configurable 400/460 Vac |
| Frequency | Hz | 50/60 | | |
| Phases: | Ph | Configurable | 1 | |
| Absorption per phase: | A | Configurable | 16.3 | 10.8 / 9.4 / 16.3 / 14.2 |
| Water properties | | | | |
| Supply water quality: | --- | See section "5.3.1 INLET WATER SPECIFICATIONS" ON PAGE 24 | | |
| Supply water conductivity: | μS*cm | 70...1250 | | |
| Supply water hardness: | °f | 5...50 | | |
| Minimum inlet flow rate: | l/h | 300 | | |
| Supply water pressure: | MPa/bar | 0.02...1/0.2...10 | | |
| Water inlet connection: | --- | M 3/4" GAS | | |
| Water outlet outside diameter: | mm (in.) | 32 (1.26) | | |
| General specifications | | | | |
| Dimensions: | mm (in.) | See section "4.1 DIMENSIONS" ON PAGE 20 | | |
| IP protection degree of the hydraulic unit: | --- | IPX0 | | |
| Maximum installation altitude: | m (ft.) | ≤2000 (6561.6) | | |
| Ambient conditions of the hydraulic unit | | | | |
| Ambient operating conditions: | °C (°F), % | 1...40 (33.8...104), 10...80% | | |
| Transportation and storage conditions: | °C (°F), % | -10...70 (14...185), 5...95% | | |
| Regulation | | | | |
| Control type/command signal: | --- | ON/OFF Proportional Probe | | |
| Supervision/Configuration: | --- | RS-485 MODBUS Supervision Wi-Fi | | |
| Compliance | | | | |
| EC: | --- | Yes, with self-certification | | |

NOTE: Models with dual hydraulic units can be created by adding an expansion to the control board, in which case the aforementioned values become the sum of those for the 2 hydraulic units chosen.

2.1.4 Large models | Zephyr OEM...

| Description | MU | EHK000000L | EHK0040T0L |
|---|------------|--|---|
| Steam production | | | |
| Production capacity: | kg/h | 20...40 | 20/30/40 |
| Pressure limits: | Pa/bar | 600/0.006 | |
| Steam connection diameter: | mm (in.) | 38 (1.50) | |
| Electrical properties | | | |
| Power absorbed: | kW | 15...30 | 15 / 22.5/30 |
| Power supply: | V | Configurable 400/460 Vac | Configurable 400/460 Vac |
| Frequency: | Hz | 50/60 | |
| Phases: | Ph | 3 | |
| Absorption per phase: | A | Configurable | 21.7 / 18.8 / 32.5 / 28.2 / 43.3 / 37.3 |
| Water properties | | | |
| Supply water quality: | --- | See section "5.3.1 INLET WATER SPECIFICATIONS" ON PAGE 24 | |
| Supply water conductivity: | μS*cm | 70...1250 | |
| Supply water hardness: | °f | 5...50 | |
| Minimum inlet flow rate: | l/h | 300 | |
| Supply water pressure: | MPa/bar | 0.02...1/0.2...10 | |
| Water inlet connection: | --- | M 3/4" GAS | |
| Water outlet outside diameter: | mm (in.) | 40 (1.57) | |
| General specifications | | | |
| Dimensions: | mm (in.) | See section "4.1 DIMENSIONS" ON PAGE 20 | |
| IP protection degree of the hydraulic unit: | --- | IPX0 | |
| Maximum installation altitude: | m (ft.) | ≤2000 (6561.6) | |
| Ambient conditions of the hydraulic unit | | | |
| Ambient operating conditions: | °C (°F), % | 1...40 (33.8...104), 10...80% | |
| Transportation and storage conditions: | °C (°F), % | -10...70 (14...185), 5...95% | |
| Regulation | | | |
| Control type/command signal: | --- | ON/OFF Proportional Probe | |
| Supervision/Configuration: | --- | RS-485 MODBUS Supervision Wi-Fi | |
| Compliance | | | |
| EC: | --- | Yes, with self-certification | |

NOTE: Models with dual hydraulic units can be created by adding an expansion to the control board, in which case the aforementioned values become the sum of those for the 2 hydraulic units chosen.

3. RECEIVING THE PRODUCT

CAUTION

IMPROPER HANDLING

- Use all necessary personal protective equipment (PPE), such as safety gloves and shoes, while handling packaging and unpacking.
- Follow the handling instruction given in this manual and any other documentation associated with the product.
- Handle and store the product in its original packaging.
- Do not handle or store the product if the packaging is or seems to be damaged.
- Take all necessary measures to avoid damaging the product and prevent other hazards while handling or opening the packaging.

NOTICE

UNEXPECTED EQUIPMENT OPERATION

- Droppages and shocks can damage the humidifier beyond repair.
- Tampering with or removing the identification stickers invalidates the warranty.

3.1 Checking the packaging

- Make sure the packaging is intact;
- Make sure the humidifier is intact upon delivery and inform the courier immediately, in writing, of any problems caused by careless or improper transportation (accept the package conditionally).

3.1.1 Opening the packaging

- Take the packages to the humidifier installation site;
- Open the cardboard boxes, removing the corner protectors;
- Take the hydraulic unit, current sensor (TA) and control board out of their packaging.

3.1.2 Checking the packaging contents

The product packaging contains:

- **Zephyr OEM** series humidifier, consisting of:
 - Hydraulic unit;
 - Instruction sheet.

4. DIMENSIONS AND MECHANICAL ASSEMBLY

4.1 Dimensions

4.1.1 Hydraulic unit




Fig. 2. Hydraulic unit dimensions

4.2 Zephyr OEM kit




Fig. 3. Installing the Zephyr OEM

| Reference | Description | Reference | Description |
|-----------|--|-----------|-----------------------------------|
| ① | Rear metal mounting panel | ⑨ | Condensate outlet pipe |
| ② | Water filling reservoir | ⑩ | Steam line distributor |
| ③ | Boiler | ⑪ | Water filter (not supplied) |
| ④ | Boiler fastening strap | ⑫ | Shut-off valve (not supplied) |
| ⑤ | Inlet solenoid valve | ⑬ | Electrodes |
| ⑥ | Electric outlet pump | ⑭ | Maximum level sensor |
| ⑦ | Water outlet circuit (not supplied) | ⑮ | Water filling pipe (not supplied) |
| ⑧ | Steam outlet pipe (can be purchased as an accessory) | | |

4.2.1 Installation hole spacing




Fig. 4. Minimum installation distances

| Zephyr OEM models | Dimension (X) [mm (in.)] | Dimension (Y) [mm (in.)] | Dimension (Z) [mm (in.)] |
|-------------------|-----------------------------|-----------------------------|-----------------------------|
| ExtraSmall | 254 (10.0) | 140 (5.51) | 106 (4.17) |
| Small | 314 (12.36) | | |
| Medium | 374 (14.72) | | |
| Large | 493.5 (19.42) | 240 (9.45) | 110 (4.33) |

5. INSTALLING THE PLUMBING

5.1 Before you start

Zephyr OEM series humidifiers are defined as "NOT ACCESSIBLE TO THE PUBLIC".

WARNING

REGULATORY INCOMPATIBILITY

Make sure all the equipment used and systems designed conform to current local, regional and national standards.

5.2 Hydraulic unit structure




Fig. 5. Hydraulic unit overview

| Reference | Description | Reference | Description |
|-----------|-----------------------------------|-----------|--|
| ① | Boiler | ⑤ | Water outlet and overflow circuit |
| ② | Electric outlet pump | ⑥ | Water filling reservoir |
| ③ | Inlet solenoid valve | ⑦ | Water outlet pipe (32 mm (1.26 in.) or 40 mm (1.57 in.)) |
| ④ | Water filling fitting, 3/4" M GAS | ⑧ | Steam outlet |

5.3 Installing the plumbing

To install the plumbing correctly, provide the following outside the air handling unit, in the immediate vicinity of the hydraulic unit:

- A shut-off tap;
- A filter supplementing the one already present inside the solenoid valve;
- A pressure reducer (if the mains pressure exceeds 1 MPa (10 bar)).

If using metal pipes, make sure they are properly earthed.

Do not use pre-existing system pipework or used materials.

Only use the materials supplied or, where appropriate, the products supplied by ELSTEAM as accessories (see "1.6 ACCESSORIES" ON PAGE 13).

NOTE: if using a pressure reducer, make sure it is effective and does not cause drastic pressure drops when the mains pressure is very low.

NOTICE

MALFUNCTIONING OF THE EQUIPMENT

- The water supply must have a minimum pressure of 0.02 MPa (0.2 bar).
- Connect the solenoid valve to the mains using the hose (available as an accessory) in order to reduce water hammer in the water supply to the humidifier.
- During installation, take care not to damage the plastic thread on the solenoid valve.
- The water connection should allow access to the mechanical filter in the inlet solenoid valve in order to clean it.
- Only connect the outlet circuit using pipes with the specifications described in this manual.
- If the air handling unit is exposed to the weather, fit heating cables to the water supply and outlet pipes.

5.3.1 Inlet water specifications

General specifications

| Description | Features |
|---------------------------------------|--|
| Water pressure | 0.02...1 MPa (0.2...10 bar) |
| Minimum instantaneous inlet flow rate | Models |
| | Value |
| | EHK0002-005 |
| | 1.2 l/min |
| EHK0010-015 | |
| 2.2 l/min | |
| EHK0020-040 | |
| 3.5 l/min | |
| Water temperature | 1...50 °C (33.8...122 °F) |
| Electrical conductivity | 75...1250 µS/cm (at a temperature of 20 °C (68 °F)) |
| Total hardness | 5...50 °f |

NOTE: Higher water hardness or a higher organic matter content does not preclude equipment operation, nevertheless these factors mean that more frequent maintenance will be required.

Optimal properties

| Description | Optimal properties with standard boiler |
|---------------------------------------|---|
| Water pressure | 1...6 bar |
| Minimum instantaneous inlet flow rate | Models |
| | Value |
| | EHK0002-005 |
| | 1.2 l/min |
| EHK0010-015 | |
| 2.2 l/min | |
| EHK0020-040 | |
| 3.5 l/min | |
| Water temperature | 7... 20 °C (44.6... 68 °F) |
| Electrical conductivity | 300...550 µS/cm |
| Total hardness | 10...25 °f |

NOTE: There is no way to establish the precise reduction in maintenance when using water with optimal properties as water morphology varies greatly even with the same hardness and electrical conductivity. In fact, the sediments that form may have different structures, from very hard to crumbly, scaly or muddy, depending on the chemical composition of the water, which is not made up of CaCO3 alone, but also of a range of other elements/compounds.

What should you do?

- Let the water drain for a few hours before making the final connection in order to drain any residues left from manufacturing and installation and ensure a free flow to the humidifier during operation.
- Check the condition of the rubber connection regularly to prevent faults that may lead to water leaks in the room.

What should you **NOT** do?

- Soften the water. If the water hardness is over 50 °f or if the hardness is such that frequent maintenance is required, mix a percentage of demineralised water with drinking water to ensure a minimum electrical conductivity of 200 µS/cm and a hardness of at least 10 °f;

NOTICE

MALFUNCTIONING OF THE EQUIPMENT

- Do not use softened water.
- Once the humidifier has been installed, let the remaining water in the pipes flow out to prevent the filter from becoming clogged.
- Make sure the humidifier parts are perfectly intact.
- If any of the humidifier parts are not intact, do not proceed with installation.

5.4 Water drainage system

The drainage system must be able to drain water at a flow rate of at least 30 l/min.

NOTICE

MALFUNCTIONING OF THE EQUIPMENT

Dimension the outlet pipe correctly in order to prevent blocking/clogging due to limescale residues while draining.

NOTE: outlet pipes are not supplied.

NOTE: a fixed outlet connection must be used.

5.4.1 Outlet connection specifications

Connecting to an open drain with tundish

Zephyr OEM 2...15 kg/h

- Minimum diameter 32 mm (1.26 in.);
- A minimum average slope of 45° with no traps or obstructions.

Zephyr OEM 20...40 kg/h

- Minimum diameter 40 mm (1.57 in.)
- A minimum average slope of 45° with no traps or obstructions.

If the installation fails to meet these specifications, install a water and limescale drain tank at the bottom of the humidifier (*p/n EHVI*) (contact the Elsteam sales office for further information).

Tank specifications

- Outlet diameter 38 mm (1.50 in.);
- Drain pipe with trap for limescale collection.

NOTICE

MALFUNCTIONING OF THE EQUIPMENT

If the water hardness is over 40 °f, carry out maintenance/manual cleaning of the tank at least twice a year.




Fig. 6. Example drain connections

If the water hardness meets the specifications indicated in section "**5.3.1 INLET WATER SPECIFICATIONS**" ON PAGE 24, the tank will only need to be cleaned once a year (water hardness in the range 5...30 °f) when only used during the winter. The maintenance technician is responsible for checking for deposit build-ups and for proper maintenance to ensure correct humidifier system operation and prevent water leaks on the surfaces around the **EHVI** tank.

If the drainage network or drainage tank is made of electrically conductive material, safety standards require it to be electrically earthed.

  **DANGER**

RISK OF ELECTRIC SHOCK

If the drainage tank is made of electrically conductive material, earth the tank or the drainage network.

Drained water may reach a temperature of 98 °C (208.4 °F) or higher.

  **WARNING**

RISK OF BURNS

- Before starting to drain the water, wear all necessary personal protective equipment (PPE).
- Do not touch the equipment when draining the water.

5.5 Steam distribution

  **WARNING**

RISK OF BURNS

- The hydraulic unit must be installed so that it cannot be accessed by unauthorised persons.
- Only qualified personnel may access the inside of the air handling unit (where the hydraulic unit is installed) using a tool (e.g. a spanner).

  **WARNING**

HOT WATER VAPOUR

Do not touch the equipment while it is running.

 **WARNING**

MALFUNCTIONING OF THE EQUIPMENT

- Install the equipment in a position which ensures the minimum distances from all adjacent structures and equipment as indicated in this document.
- Install all equipment in compliance with the technical specifications indicated in the relevant documentation.

NOTE: in ambient temperature conditions which may lead to the formation of ice, it is wise to take all necessary precautions to prevent the supply water and the drain water from freezing and causing the humidifier to malfunction.

6. ELECTRICAL CONNECTIONS

6.1 Before you start

Read this manual carefully before installing the equipment.

In particular, the safety instructions, electrical requirements and current regulations for the machine or the process in which this device is involved must be observed.

The use and application of the information contained herein requires experience in the design and installation of humidification systems. Only the user, integrator or manufacturer of the machine can be familiar with all the conditions and factors which arise during installation and configuration, operation and maintenance of the machine or the process, and as such can identify the relevant automation equipment and the corresponding interlocks and safety systems which can be used effectively and appropriately. When selecting automation and control equipment and other connected equipment and software, for a particular application, you must consider all applicable local, regional and national standards and/or regulations.

DANGER

RISK OF ELECTRIC SHOCK, EXPLOSION OR ELECTRIC ARC

- Only use electrically insulated measuring devices and equipment.
- Do not install the equipment while the power supply is connected.
- Cut off the power supply to all equipment, including any connected devices, before installing/uninstalling accessories, hardware, cables or wires.
- Provide safety interlocks (isolators) of a suitable size between the power supply and the humidifier, with a contact opening distance of at least 3 mm for each pole.
- Always use a properly calibrated Voltmeter to make sure the system is powered off.
- The maintenance, repair, installation and use of the equipment must only be entrusted to qualified personnel.
- Do not touch the unshielded components or the terminals while they are live.
- Do not open, disassemble, repair or modify the product.
- Do not expose the equipment to liquids or chemicals.
- Make sure there is an effective earth connection.
- Before applying voltage to the equipment:
 - Make sure all protective elements, such as covers, hatches and grilles, are fitted and/or closed using a tool (e.g. a spanner).
- Check all wiring connections.

WARNING

REGULATORY INCOMPATIBILITY

Make sure all the equipment used and systems designed conform to current local, regional and national standards.

6.2 Connection best practice

6.2.1 Wiring best practices

DANGER

RISK OF ELECTRIC SHOCK AND FIRE

- Do not use the device with loads greater than those indicated in the technical data section.
- Do not exceed the temperature and humidity ranges indicated in the technical data section.
- Provide safety interlocks (isolators) of a suitable size between the power supply and the humidifier.
- Only use cables with a suitable cross-section as indicated in the section "Wiring best practices".

When wiring the humidifiers, observe the following instructions:

- Make sure the operating environment and conditions fall within the specified values.
- Use cables with the correct diameter, suited to the voltage and current requirements.
- Use double-insulated cables suitable for outdoor use (minimum requirement: H05RN-F) which also include an earth wire.

DANGER

LOOSE WIRING CAUSES ELECTRIC SHOCKS AND OVERHEATING

Tighten the connections in compliance with the technical specifications relating to tightening torques.

WARNING

MALFUNCTIONING OF THE EQUIPMENT

- Perform the wiring carefully, in compliance with electromagnetic compatibility and safety requirements.
- Carry out a full start-up test.
- Make sure the wiring is correct for the end application.
- Minimise the length of the connections as much as possible, to avoid winding the cables around electrically connected parts.
- Before applying the power supply, check all the wiring connections.
- Do not connect cables to unused terminals and/or terminals marked with the text "No connection" (N.C.).

⚠ WARNING

REGULATORY INCOMPATIBILITY

Make sure all the equipment used and systems designed conform to current local, regional and national standards.

6.3 Dimensioning electrical components

| Configurations (*) | Steam prod. [kg/h] | Power supply [V, 50/60 HZ] | Power [kW] | Nominal current [A] | High current alarm [A] | Fuse type | 24 Vac power | Maximum current during use (**) | TA management (***) | Boiler cable type (#) | Back pressure [max mm H2O] |
|--------------------|--------------------|----------------------------|--|---------------------|------------------------|-----------------|--------------|---------------------------------|---------------------|-----------------------|----------------------------|
| EHK0000XS | --- | 230 Vac single-phase | Maximum 2.2 | --- | --- | --- | 60 VA | --- | External | --- | 50 |
| EHK0002M2XS | 2 | 230 Vac single-phase | 1.5 | 6.5 | 9.8 | 10x38 10A gG | | 20 A | | 3x2.5 mm ² | |
| EHK0003T4XS | 3 | 400 Vac three-phase | 2.2 | 3.2 | 4.8 | 10x38 10A gG | | | | | |
| EHK0003T5XS | | 460 Vac three-phase | 2.2 | 2.8 | 4.2 | 10x38 10A gG | | | | | |
| EHK00000S | --- | Configurable | 1ph: max 2.2 3ph: max 6 | --- | --- | --- | 60 VA | --- | External | --- | 50 |
| EHK0003M2S | 3 | 230 Vac single-phase | 2.2 | 9.6 | 14.3 | 10x38 16A gG | | 20 A | | 3x2.5 mm ² | |
| EHK0005T4S | | 400 Vac three-phase | 3.75 | 5.4 | 8.1 | 10x38 10A gG | | | | | |
| EHK0005T5S | 5 | 460 Vac three-phase | 3.75 | 4.7 | 7.1 | 10x38 10A gG | | 3x2.5 mm ² | | | |
| EHK0008T4S | 8 | 400 Vac three-phase | 6 | 8.6 | 12.9 | 10x38 16A gG | | | | | |
| EHK0008T5S | | 460 Vac three-phase | 6 | 7.5 | 11.3 | 10x38 16A gG | | | | | |
| EHK00000M | --- | Configurable | 1ph: max 3.75 3ph: max 11.3 | --- | --- | --- | 60 VA | --- | External | --- | 50 |
| EHK0005M2M | 3...5 | 230 Vac single-phase | 3.75 | 16.3 | 24.5 | 10x38 32A gG | | 25 A | | 3x2.5 mm ² | |
| EHK0010T4M | 5...15 | 400 Vac three-phase | 7.5 | 10.8 | 16.2 | 10x38 16A gG | | 20 A | | | |
| EHK0010T5M | | 460 Vac three-phase | 7.5 | 9.4 | 14.1 | 10x38 16A gG | | 20 A | | 3x6 mm ² | |
| EHK0015T4M | | 400 Vac three-phase | 11.3 | 16.3 | 24.5 | 10x38 32A gG | | 25 A | | | |
| EHK0015T5M | | 460 Vac three-phase | 11.3 | 14.2 | 21.3 | 10x38 32A gG | | 25 A | | | |
| EHK00000L | --- | 400 Vac three-phase | Maximum 30 | --- | --- | --- | 60 VA | --- | External | --- | 60 |
| EHK0020T4L | 20...40 | 400 Vac three-phase | 15 | 21.7 | 32.6 | 14x51 40A gG | | 45 A | | 3x10 mm ² | |
| EHK0020T5L | | | 15 | 18.8 | 28.2 | 14x51 40A gG | | 45 A | | | |
| EHK0030T4L | | | 22.5 | 32.5 | 48.8 | 14x51 50A gG | | 56 A | | 3x10 mm ² | |
| EHK0030T5L | | | 22.5 | 28.2 | 42.3 | 14x51 50A gG | | 45 A | | | |
| EHK0040T4L | | | 30 | 43.3 | 65.0 | 22x58 80A gG | | 70 A | | 3x16 mm ² | |
| EHK0040T5L | | | 30 | 37.3 | 56.0 | 22x58 80A gG | | 56 A | | | |

(*) EHHKT011P4 electronic control

(**) Temperatures up to 40°C – 24 Vac contactor coil – Check the offsets at 55 and 70°C, and size in accordance with current regulations

(***) L = 2 m maximum voltage drop of 0.2 V

(#) P/n 0103349007

6.4 Electrical connections

6.4.1 Control board




Fig. 7. Control board electrical connections

| TERMINALS | |
|--------------|--|
| 1-2 | 24 Vac power supply |
| 1-3 | Digital output: water outlet solenoid valve |
| 1-4 | Digital output: water outlet pump |
| 1-5 | Digital output: contactor (steam generation) |
| 6-7 | Digital output: dehumidification enable |
| 8-9 | Digital output: ventilated distributor control |
| 10...12 | Digital output: alarm |
| 13-14 | Hazardous voltage digital input: level sensor LS1 |
| 20-21 | Digital input: fan enable (CV) |
| 22-23 | Digital input: remote ON/OFF (0/1) |
| 24-25 | Digital input: humidistat (CFG = 0-1) (S0) |
| 26-27 | S1 analogue input: temperature (anti-freeze and hold) |
| 28...30 | S2 analogue input: humidity sensor |
| 31...33 | S3 analogue input: humidity limit sensor |
| 34...36 | Serial line connection: HMI Intrabus |
| 38...40 | Serial line connection: RS-485 modbus for BMS slave |
| 45-46 | Analogue connection: external current sensor CT1 (TA) |
| 47...50 | Connection to expansion board SCI1 |
| 51-52 | Reserved |
| TERM3 | Activate termination resistor on the SCI1 RS-485 serial line. ON = Termination resistor enabled; off = Disabled. |
| TERM1 | Termination resistor on BMS RS-485 serial line. ON = Termination resistor enabled; off = Disabled. |
| TERM2 | Termination resistor on CANBUS serial line. ON = Termination resistor enabled; off = Disabled. |

6.4.2 Power supply and earth wiring connection

  **DANGER**

RISK OF ELECTRIC SHOCK

Make sure that the entire system is earthed to the highest standards.

6.5 Configurations

6.5.1 ON/OFF connection with humidistat or external contact (CFG = 0-1)

| Configuration |
|--------------------|
| CFG = 0-1 |
| CV input = Closed |
| 0/1 input = Closed |




Fig. 8. ON/OFF connection with humidistat or external contact (CFG = 0-1)

NOTE: To start humidity production, the **CV** and **0/1** contacts must be closed.

6.5.2 External proportional humidistat connection (CFG = PROP)

| Configuration |
|--------------------|
| CFG = PROP |
| P2 = 0-10 |
| P2 = 0-5 |
| P2 = 0.20 |
| P2 = 4.20 |
| CV input = Closed |
| 0/1 input = Closed |




Fig. 9. External proportional humidistat connection (CFG = PROP)

NOTE: To start humidity production, the **CV** and **0/1** contacts must be closed.

6.5.3 Humidity sensor connection (CFG = HUM)

| Configuration |
|--------------------|
| CFG = HUM |
| P2 = 0-10 |
| P2 = 0-5 |
| P2 = 0.20 |
| P2 = 4.20 |
| CV input = Closed |
| 0/1 input = Closed |

S2 input
29 = Sensor signal input
30 = Sensor power supply




Fig. 10. Humidity sensor connection (CFG = HUM)

NOTE: To start humidity production, the **CV** and **0/1** contacts must be closed.

6.5.4 EVHTP520 humidity sensor connection (CFG = HUM and CFG = HUML)

| Configuration |
|--------------------|
| CFG = HUM |
| CFG = HUML |
| P2 = E520 |
| P7 = E520 |
| CV input = Closed |
| 0/1 input = Closed |




Fig. 11. EVHTP520 humidity sensor connection (CFG = HUM and CFG = HUML)

NOTE: To start humidity production, the CV and 0/1 contacts must be closed.

6.5.5 Connection for humidity sensor and limit sensor (CFG = HUML)

| Configuration |
|--------------------|
| CFG = HUML |
| P2 = 0.20 |
| P2 = 4.20 |
| P7 = 0.20 |
| P7 = 4.20 |
| CV input = Closed |
| 0/1 input = Closed |

S2 input
29 = Sensor signal input
30 = Sensor power supply

S3 input
32 = Sensor signal input
33 = Sensor power supply




Fig. 12. Connection for humidity sensor and limit sensor (CFG = HUML)

NOTE: To start humidity production, the CV and 0/1 contacts must be closed.

6.5.6 Humidity sensor connection 0...5 V / 0...10 V

| Configuration |
|--------------------|
| CFG = HUM |
| CFG = HUML |
| P2 = 0-5 |
| P2 = 0-10 |
| P7 = 0-5 |
| P7 = 0-10 |
| CV input = Closed |
| 0/1 input = Closed |

S2 input
28 = GND
29 = V+
30 = Sensor power supply

S3 input
31 = GND
32 = V+
33 = Sensor power supply




Fig. 13. Humidity sensor connection 0...5 V / 0...10 V

NOTE: To start humidity production, the CV and 0/1 contacts must be closed.

6.5.7 Temperature sensor connection (CFG = 1T)

| Configuration |
|--|
| CFG = 1T |
| P2 = PTC P2 = 1000 P2 = NTC |
| CV input = Closed |
| 0/1 input = Closed |




Fig. 14. Temperature sensor connection (CFG = 1T)

NOTE: To start humidity production, the **CV** and **0/1** contacts must be closed.

6.5.8 Connection for two temperature sensors (CFG = 2T)

| Configuration |
|--|
| CFG = 2T |
| P2 = PTC P2 = 1000 P2 = NTC |
| P7 = PTC P7 = 1000 P7 = NTC |
| CV input = Closed |
| 0/1 input = Closed |




Fig. 15. Temperature sensor connection (CFG = 2T)

NOTE: To start humidity production, the **CV** and **0/1** contacts must be closed.

6.6 DIP switch functions

The control board and the expansion board have dip switches to configure the termination resistors and the Modbus address of the expansion board.

6.6.1 DIP switch | Control board

| DIP | Description | Description |
|--------------|--|--|
| TERM3 | Activate termination resistor on the SCI1 RS-485 serial line. ON = Termination resistor enabled; off = Disabled. | Set to ON if connected to the expansion, but only if it is the first or last element wired in the network. |
| TERM1 | Termination resistor on BMS RS-485 serial line. ON = Termination resistor enabled; off = Disabled. | Set to ON if connected to the MODBUS network, but only if it is the first or last element wired in the network. |
| TERM2 | Termination resistor on CANBUS serial line. ON = Termination resistor enabled; off = Disabled. | Set to ON only if it is the first or last element wired in the network. It must be ON if wired to an EPJ terminal. |

6.6.2 DIP switch | Expansion

| DIP | Description | Description | |
|--------------|---|---|-------------------------|
| DP1 | Modbus communication address of expansion board | | |
| | ADDR1 | ADDR2 | Expansion board address |
| | OFF | OFF | 2 |
| | OFF | ON | 3 |
| | ON | OFF | 4 |
| | ON | ON | 5 |
| TERM1 | Activate termination resistor on SCI1 RS-485 serial line. ON = Termination resistor enabled; off = Disabled. | Set to ON if connected to the expansion, but only if it is the first or last element wired in the network. | |

7. USER INTERFACE (OPTIONAL)

Make sure the humidifier and all the installed components are properly connected before start-up, in accordance with regulations, criteria and all applicable local, regional and national standards.

7.1 User interface



Fig. 16. Zephyr OEM humidifier user interface (optional)

7.1.1 Icons

| Icon | Lit steadily | OFF | Icon | Lit steadily | OFF |
|------|--|--------------------|------|--|---|
| 1 | <ul style="list-style-type: none"> Main sensor configured and present CFG = 1T (one temperature probe) | In all other cases | ⚠ | Warning in progress | No warning in progress |
| 2 | <ul style="list-style-type: none"> Limit sensor configured and present CFG = 2T (two temperature probes) | In all other cases | 🔗 | CV input closed (enable signal given) | CV input open (enable signal not given) |
| 🌀 | Steam request | In all other cases | SP | Changing humidity setpoint in progress | In all other cases |
| 📈 | Proportional operating mode | In all other cases | ⚠ | Alarm in progress | No active alarms |
| 📉 | ON/OFF operating mode | In all other cases | ⚡ | Contactor ON | Contactor OFF |
| 🔌 | Humidifier OFF | Humidifier ON | 🌀 | Washing or draining in progress | In all other cases |
| V | Voltage sensor operating mode | In all other cases | 🕒 | Displayed value is operating hours | In all other cases |
| I | Current sensor operating mode | In all other cases | F | Display shows temperature in °F | In all other cases |
| R | Resistive sensor operating mode | In all other cases | % | Display shows humidity in % | In all other cases |
| A | Display shows the current absorbed by the electrodes | In all other cases | °C | Display shows temperature in °C | In all other cases |
| μS | Changing value of P1 in progress | In all other cases | | | |

7.1.2 Keys

| Key... | Tap and release to... | Tap and hold for at least 3 seconds to... |
|--------|---|--|
| 🔌 | Go back a level | Humidifier ON/OFF |
| FNC ✓ | <ul style="list-style-type: none"> Scroll down through the values Navigate within the menu | Go to the maintenance and reset operating hours menu |
| ^ | <ul style="list-style-type: none"> Scroll up through the values Navigate within the menu | Activate manual draining |
| 🔒 SET | <ul style="list-style-type: none"> Confirm the values on the display Set/change the humidity setpoint | Enter the main menu |

7.1.3 First start-up

Make sure the humidifier and all the installed components are properly connected before start-up, in accordance with regulations, criteria and all applicable local, regional and national standards.

At the first start-up, you must enter the electrical conductivity of the inlet water, after which the humidifier OFF screen will open automatically.

NOTE: If you do not know the electrical conductivity of the water, it can be obtained from the drinking water supplier's website.



Fig. 17. First start-up - Setting the electrical conductivity




Fig. 18. Humidifier OFF

7.2 User interface menu

7.2.1 Home screen

HOME screen with ON/OFF regulation from digital input (CFG = 0-1)



Fig. 19. Home screen with ON/OFF regulation from digital input (CFG = 0-1)

Top line: Shows the state of the digital control input (S0).

NOTE: The CV and 0/1 contacts must be closed to produce humidity.

HOME screen with proportional regulation (CFG = PROP)




Fig. 20. Home screen with proportional regulation (CFG = PROP)

Top line: Actual humidity request in %.

NOTE: The CV and 0/1 contacts must be closed to produce humidity.

HOME screen with regulation via humidity sensor (CFG = HUM) or humidity sensor and limit sensor (CFG = HUML)




Fig. 21. Home screen with humidity sensor alone




Fig. 22. Home screen with humidity sensor and limit sensor

Top line: Humidity measured by the room humidity sensor.

Bottom line: Humidity setpoint.

NOTE: The CV and O/1 contacts must be closed to produce humidity.

7.2.2 Changing the main sensor humidity setpoint

With CFG = HUM or CFG = HUML only.

To change the humidity setpoint:




Fig. 23. Changing the humidity setpoint

7.2.3 Changing the temperature setpoint

With CFG = 1T or CFG = 2T only.

To change the temperature setpoint:




Fig. 24. Changing the temperature setpoint

7.2.4 Manual draining

To start manual draining:




Fig. 25. Manual draining

7.2.5 Menu




Fig. 26. Menu

| Menu | Description |
|--------------|--|
| <i>USER</i> | Access the user menu |
| <i>NA in</i> | Access the maintenance technician menu |
| <i>NA nF</i> | RESERVED. NOT ACCESSIBLE TO THE PUBLIC. |
| <i>AL n</i> | Currently accessing alarm control |
| <i>H. St</i> | Access the alarm log |
| <i>SEtt</i> | Reset parameters to factory settings |

7.2.6 User Menu

The user menu can be used to display and change user parameters.

To access the user menu:




Fig. 27. User menu

| Top line | Bottom line | Description |
|-------------|-------------------------|--|
| LANg | Set language | Sets the display language. EnG = English; Ita = Italian. |
| SP1 | Humidity setpoint | Sets the humidity setpoint. See " 9.10 TABLE OF ADJUSTMENT PARAMETERS " ON PAGE 50 |
| SP2 | Humidity limit setpoint | Sets the humidity limit setpoint`. See " 9.10 TABLE OF ADJUSTMENT PARAMETERS " ON PAGE 50 |
| SP3 | Temperature setpoint | Sets the temperature setpoint (wellness application). See " 9.10 TABLE OF ADJUSTMENT PARAMETERS " ON PAGE 50 |

7.2.7 Maintenance menu

To access the maintenance menu:




Fig. 28. Maintenance menu

The following is a table with the labels shown on the display and their description:

| Top line | Bottom line | Description |
|-----------------|------------------------------------|--|
| SP1 | Setpoint SP1 value | Displays the value of setpoint SP1 . |
| SP2 | Setpoint SP2 value | Displays the value of setpoint SP2 . |
| SP3 | Setpoint SP3 value | Displays the value of setpoint SP3 . |
| CFG | Set operating mode | Sets the operating mode See "9.10 TABLE OF ADJUSTMENT PARAMETERS" ON PAGE 50 |
| c0...c11 | Parameter value | See "9.10 TABLE OF ADJUSTMENT PARAMETERS" ON PAGE 50 |
| S1 | Sensor S1 value | Displays the value read by sensor S1 if it is connected. |
| S2 | Sensor S2 value | Displays the value read by sensor S2 if it is connected. |
| S3 | Sensor S3 value | Displays the value read by sensor S3 if it is connected. |
| tA | Sensor tA value | Displays the value read by sensor CT1 if it is connected. |
| CU | CV input status. | Displays the status of the CV digital input (fan enable) if it is connected. OFF = CV input closed; On = CV input open. |
| OI | 0/1 input status | Displays the status of the 0/1 digital input (remote ON/OFF) if it is connected. OFF = 0/1 input closed; On = 0/1 input open. |
| SO | S0 input status | Displays the status of the S0 digital input (remote humidistat enable) if it is connected. OFF = S0 input closed; On = S0 input open. |
| LS | LS1 input status | Displays the status of the LS1 digital input (level sensor) if it is connected. OFF = LS1 input closed; On = LS1 input open. |
| oEU | Inlet solenoid valve output status | Displays the status of the inlet solenoid valve. OFF = Inlet solenoid valve output OFF; ON = Inlet solenoid valve output ON. |
| oP | Outlet pump status | Displays the status of the outlet pump. OFF = Outlet pump output OFF; ON = Outlet pump output ON. |

| Top line | Bottom line | Description |
|-------------|---------------------------------------|---|
| oS | Steam generation contactor status | Displays the status of the steam generator contactor. OFF = Steam generator electrode output OFF; ON = Steam generator electrode output ON. |
| od | Dehumidification enable output status | Displays the status of the dehumidification enable output. OFF = Dehumidification enable output OFF; ON = Dehumidification enable output ON. |
| oF | Fan output status | Displays the status of the fan digital output. OFF = Fan output OFF; ON = Fan output ON. |
| oAL | General alarm output status | Displays the status of the general alarm output. OFF = General alarm output OFF; ON = General alarm ON. |
| HrS | Operating hours management page | Enters the page that displays the operating hours of the humidifier and its parts. To access the page: Double tap the SET key, enter password PA2 using the FNC \checkmark or \wedge keys, and tap SET to confirm. |
| MAnu | Output forcing page | Enters the output forcing page. To access the page: Double tap the SET key, enter password PA2 using the FNC \checkmark or \wedge keys, and tap SET to confirm. |

7.2.8 Displaying/resetting the operating hours

The operating hours can be displayed and reset from the maintenance menu.




Fig. 29. Displaying the operating hours

The following is a table with the labels shown on the display and their description:

| Top line | Bottom line | Description |
|------------|--------------------|---|
| SH | Humidifier hours | Displays the hours of humidifier operation. |
| PbH | Partial H.U. hours | Displays the partial hours of hydraulic unit operation. |
| tbH | Total H.U. hours | Displays the total hours of hydraulic unit operation. |
| EUH | Inlet SV hours | Displays the hours of outlet solenoid valve operation. |
| PH | Outlet pump hours | Displays the hours of outlet pump operation. |
| FH | Fan hours | Displays the operating hours of the fans. |

Reset operating hours

The operating hours can be reset by setting the parameters to 0.

7.2.9 Output functional test

The output functional test page can be accessed from the maintenance menu. Here the outputs can be forced on or off:




Fig. 30. Output functional test

The table below contains the labels shown on the display and their descriptions:

| Top line | Bottom line | Description |
|----------|---------------------------------------|---|
| SEU | Inlet SV output status | Forces the inlet solenoid valve output on/off. OFF = Inlet solenoid valve output forced OFF; ON = Inlet solenoid valve output forced ON. |
| SP | Outlet pump output status | Forces the outlet pump output on/off. OFF = Outlet pump output forced OFF; ON = Outlet pump output forced ON. |
| SS | Steam generation contactor status | Forces the steam generation contactor on/off. OFF = Steam generator electrode output forced OFF; ON = Steam generator electrode output forced ON. |
| Sd | Dehumidification enable output status | Forces the dehumidifier enable output on/off. OFF = Dehumidification enable output forced OFF; ON = Dehumidification enable output forced ON. |
| SF | Fan output status | Forces the fan output on/off. OFF = Fan output forced OFF; ON = Fan output forced ON. |
| SAL | General alarm output status | Forces the general alarm output on/off. OFF = General alarm output forced OFF; ON = General alarm output forced ON. |

8. POWER-UP AND START-UP

8.1 First start-up instructions

DANGER

RISK OF ELECTRIC SHOCK, EXPLOSION OR ELECTRIC ARC

- Do not install the equipment while the power supply is connected.
- Cut off the power supply to all equipment, including any connected devices, and remove the power fuses before removing any covers or hatches, or before installing/uninstalling accessories, hardware, cables or wires.
- Always use a properly calibrated Voltmeter to make sure the system is powered off.
- Do not touch the unshielded components or the terminals while they are live.
- Make sure there is an effective earth connection; if there is not, earth the equipment.
- Before applying voltage to the equipment:
 - Make sure all protective elements, such as covers, hatches and grilles, are fitted and/or closed.
 - Check all wiring connections.

NOTICE

MALFUNCTIONING OF THE EQUIPMENT

- Make sure the water mains is correctly connected.
- Make sure there are no traps in the drainage duct.
- Make sure the steam outlet closure clamps are properly tightened.
- Make sure there are no pockets of condensate or throttling in the steam delivery channel.

Make sure the humidifier and all the installed components are properly connected before start-up, in accordance with regulations, criteria and all applicable local, regional and national standards.

At the first start-up, the machine is disabled until the inlet water conductivity has been entered, after which the humidifier OFF screen will open automatically.

To start the humidifier (with humidistat connected or sensor connected if in proportional mode):

- Check the filling and drain network (see sections: "**5.3 INSTALLING THE PLUMBING**" ON PAGE 24, "**5.4 WATER DRAINAGE SYSTEM**" ON PAGE 25 and "**5.5 STEAM DISTRIBUTION**" ON PAGE 26);
- Let the water flow through the drain for a few hours before making the final connection;
- Fit the power fuses;
- Connect the humidistat or the probe in accordance with the required operation (**SEE "6.4 ELECTRICAL CONNECTIONS" ON PAGE 29**);
- Check that the **CV** and **0/1** contacts are closed, see "**6.4 ELECTRICAL CONNECTIONS**" ON PAGE 29;
- Activate the isolator installed outside the humidifier and open the water supply source;
- Start the humidifier according to the start-up instructions provided by the OEM manufacturer;
- Set the electrical conductivity of the inlet water (if you do not know the electrical conductivity of the water, it can be obtained from the drinking water supplier's website);
- Set the humidity request setpoint **SP** to 100%;
- The humidifier starts a boiler loading cycle;
- Set the humidity setpoint **SP** to the value required for the application;
- The humidifier drains the water and replenishes it cyclically to perform the dilution procedure in order to keep the humidifier in a good operating condition. The humidifier cyclically carries out a full wash and then restarts with a lower frequency. Operation has been developed to ensure maximum energy efficiency and optimal water use.

8.2 Instructions for seasonal or long-term shut-down

If you need to switch off the humidifier for long periods of time, you must:

- Manually drain the product using the manual drainage launch procedure;
- When draining is complete, deactivate the isolator installed outside the humidifier and open the water supply source;
- Open the manual drain plug to complete draining the manifold and pump.

WARNING

BIOLOGICAL RISK

- In the event of poor maintenance/cleaning after the humidifier has been shut-down for a long time, microorganisms (including the bacteria that cause Legionellosis) may proliferate and be transferred into the air treatment system.
- The humidifier must be used correctly and be maintained and cleaned properly at the prescribed intervals, as described in the **MAINTENANCE** chapter.

8.3 Starting up after a seasonal or long-term shut-down

- It is advisable to clean the boiler before a seasonal start-up;
- Check the steam inlet and outlet lines (see sections: "**5.3 INSTALLING THE PLUMBING" ON PAGE 24**, "**5.4 WATER DRAINAGE SYSTEM" ON PAGE 25** and "**5.5 STEAM DISTRIBUTION" ON PAGE 26**);
- Let the water flow through the drain for a few hours before making the final connection;
- Check the power fuses;
- Check the humidistat or sensor connections, depending on the required operation (**SEE "6.4 ELECTRICAL CONNECTIONS" ON PAGE 29**);
- Check that the **CV** and **0/1** contacts are closed, see "**6.4 ELECTRICAL CONNECTIONS" ON PAGE 29**;
- Activate the isolator installed outside the humidifier and open the water supply source;
- Start the humidifier according to the start-up instructions provided by the OEM manufacturer;
- Set the electrical conductivity of the inlet water (if you do not know the electrical conductivity of the water, it can be obtained from the drinking water supplier's website);
- Set the humidity request setpoint **SP** to 100%;
- The humidifier starts a boiler loading cycle;
- Set the humidity setpoint **SP** to the value required for the application;
- The humidifier drains the water and replenishes it cyclically to perform the dilution procedure in order to keep the humidifier in a good operating condition. The humidifier cyclically carries out a full wash and then restarts with a lower frequency. Operation has been developed to ensure maximum energy efficiency and optimal water use.

9. OPERATION

9.1 Principle of operation

The **Zephyr OEM** humidifier is the ELSTEAM solution for immersed electrode humidifier systems dedicated to PAC/CLOSE CONTROL applications and to all applications that require small kits to install the electrical part for remote management of the hydraulic part.

ZEPHYR series humidifiers generate humidity (steam) by means of a current passing between 2 or 3 electrodes immersed in drinking water to bring it to boiling point.

The steam is controlled by adjusting the intensity of the current transferred to the water by the immersed electrodes, which indirectly controls the boiling of the water.

The steam is introduced into the air handling unit by means of a steam hose and a linear distributor, after placing the OEM kit inside the compartment provided by the manufacturer.

9.2 Humidity regulation

The humidity can be regulated in 6 ways, depending on how the **CFG** parameter is set:

- ON-OFF regulation (**CFG** = 0-1);
- Proportional regulation (**CFG** = PROP);
- Regulation with the humidity sensor (**CFG** = HUM);
- Regulation with the humidity sensor and limit sensor (**CFG** = HUML);
- Regulation with a temperature probe (wellness applications) (**CFG** = 1T);
- Regulation with two temperature probes (wellness applications) (**CFG** = 2T)

9.2.1 ON-OFF regulation | CFG = 0-1

To use the **Zephyr OEM** with ON-OFF regulation, the following conditions must be met:

- **CFG** = 0-1;
- Enable digital input closed (**CV**);
- Remote ON/OFF digital input closed (**0/1**).

When the **S0** digital input is closed, the **Zephyr OEM** generates humidity at the maximum value set in parameter **r6**.

9.2.2 Proportional regulation | CFG = PROP

To use the **Zephyr OEM** with proportional regulation, the following conditions must be met:

- **CFG** = PROP;
- Set the minimum humidity production **r5**;
- Set the maximum humidity production **r6**;
- Enable digital input closed (**CV**);
- Remote ON/OFF digital input closed (**0/1**).

The humidity production varies with the value read at the **S1** analogue input, with the logic expressed in the graph below, without exceeding parameter **r6**:





Fig. 31. How proportional regulation works | **CFG** = PROP

9.2.3 Regulation with the humidity sensor | CFG = HUM

To use the **Zephyr OEM** with regulation based on a humidity sensor, the following conditions must be met:

- **CFG = HUM** or **CFG = HUML**;
- Set parameter **P2** according to the sensor type to be used;
- Set the minimum humidity production **r5**;
- Set the maximum humidity production **r6**;
- Enable digital input closed (**CV**);
- Remote ON/OFF digital input closed (**0/1**).



| KEY | |
|------|-------------|
| Line | Description |
| | V_{in} |
| | Production |




Fig. 32. How regulation with the humidity sensor works | CFG = HUM

9.2.4 Regulation with the humidity sensor + limit sensor | CFG = HUML

To use the **Zephyr OEM** with regulation based on a humidity sensor and limit sensor, the following conditions must be met:

- **CFG = HUML**;
- Set parameter **P2** according to the sensor type to be used;
- Set parameter **P7** according to the limit sensor type to be used;
- Set the minimum humidity production **r5**;
- Set the maximum humidity production **r6**;
- Enable digital input closed (**CV**):
- Remote ON/OFF digital input closed (**0/1**).




Fig. 33. How regulation with the humidity sensor + limit sensor works | **CFG = HUML**

Humidity production behaves in the same way as for regulation with the humidity sensor (**CFG = HUM**), but the second sensor connected to analogue input **S2** stops steam generation, depending on the humidity delivery.

The humidity limit activates when the humidity measured by sensor **S2** exceeds **SP + r10**.

9.2.5 Regulation with a temperature probe | CFG = 1T

To use the **Zephyr OEM** with regulation based on a temperature sensor, the following conditions must be met:

- **CFG** = 1T;
- Set parameter **P0** according to the sensor type to be used
- Set the minimum humidity production **r5**;
- Set the maximum humidity production **r6**;
- Enable digital input closed (**CV**):
- Remote ON/OFF digital input closed (**0/1**).

Principle of operation

The humidity requirement is managed with proportional temperature regulation between **SP3** and the proportional band **r20**, according to the following logic:

- Temperature \geq **SP3**: 0% humidity request;
- Temperature \leq **SP3 - r20**: humidity request at **r6**;
- **SP3** < Temperature < **r20**: proportionally linearised humidity request (minimum production **r5**).

9.2.6 Regulation with two temperature probes | CFG = 2T

To use the **Zephyr OEM** with regulation based on two temperature sensors, the following conditions must be met:

- **CFG** = 2T;
- Set parameter **P0** according to the sensor type to be used
- Set the minimum humidity production **r5**;
- Set the maximum humidity production **r6**;
- Set parameter **r23**;
- Set parameter **r24**;
- Enable digital input closed (**CV**);
- Remote ON/OFF digital input closed (**0/1**).

9.3 Water dilution

Water dilution in the hydraulic unit is controlled in two ways, depending on how parameter **c3** is set:

| Par. | Description | MU | Range |
|-----------|--|-----|-------|
| c3 | Type of draining for dilution. 0 = Current-based; 1 = Time-based. | --- | 0/1 |

NOTE: The electrodes are off while draining the water. Draining is activated 3 seconds after turning the electrodes off.

9.3.1 Current-based water dilution

Setting **c3** = 0 configures water dilution based on the measured currents.

The evaporation cycle and water filling times to reach the required production are monitored during operation.

The electrical conductivity of the water tends to rise while producing humidity because it concentrates the substances in the water, and consequently the times mentioned above tend to reduce; during this stage, the **Zephyr OEM** activates the outlet pump until the internal current drops below the threshold set in parameter **c6**.

NOTE: The electrodes are off during draining to ensure safety.

The configuration parameters for current-based water dilution are:

| Par. | Description | MU | Range |
|-----------|---|----|---------|
| c6 | Draining value for dilution (if C3 = 0). | % | 20...80 |

9.3.2 Time-based water dilution

Setting **c3** = 1 configures time-based water dilution to ensure that the water is diluted periodically without waiting for the internal conditions to become critical.

The **Zephyr OEM** dilutes the water after time **c5** for a duration of **c4**.

The configuration parameters for time-based water dilution are:

| Par. | Description | MU | Range |
|-----------|---|-----|----------|
| c4 | Draining duration for dilution (if C3 = 1). | s | 0...9999 |
| c5 | Time between two dilution draining events (if C3 = 1). | min | 30...999 |

9.4 Hydraulic unit draining

When the electrical conductivity of the water becomes too high, the hydraulic unit must be drained completely to restore optimal operating conditions.

The evaporation cycle and water filling times to reach the required production are monitored during operation.

Once it has been completely drained, it is washed a second time if the **Zephyr OEM** detects that the unfavourable conditions persist; if the second washing fails to create optimal operating conditions, alarm **AL08** is generated and the humidifier is forced OFF until maintenance is carried out (see "**12.1 ZEPHYR OEM ALARMS TABLE**" ON PAGE 61).

9.5 Complete hydraulic unit emptying

The **Zephyr** hydraulic unit must be emptied completely in the following cases:

- After the inactivity time set in parameter **c0**;
- After the activity time set in parameter **c1**;
- If the timer is not working, when the humidifier is powered up;
- Whenever electrical power is supplied;
- When manual draining is activated from the user menu.

The configuration parameters for the cleaning cycles are:

| Par. | Description | MU | Range |
|-----------|--|------|---------|
| c0 | Number of consecutive days of inactivity after which the hydraulic unit is emptied. 0 = Function disabled. | days | 0...10 |
| c1 | Number of consecutive days of activity after which the hydraulic unit is emptied. 0 = Function disabled. | days | 0...100 |

9.6 Level sensor

When the humidifier is running, the water may exceed the level sensor at the top of the hydraulic unit. This is caused by low electrical conductivity of the water in the boiler. The **Zephyr OEM** activates the outlet pump to drain it partially and resumes the evaporation cycles to achieve optimum electrical conductivity.

9.7 Foam management

Foaming may occur while the water is boiling in the hydraulic unit. Foaming is generally due to surfactants (manufacturing residues in the water filling system, water treatment agents, softeners) or an excessive concentration of dissolved salts in the water.

If **c11** = 1, the **Zephyr OEM** indicates and manages this condition.

If there is no foam in the boiler, the **Zephyr OEM** resumes normal operation.

If the level sensor is reached again within time **c12**, there is foam in the boiler. The **Zephyr OEM** empties the boiler completely. Thereafter, if the following occurs within time **c12**:

- The level sensor is reached again, and the **Zephyr OEM** performs two complete washing cycles;
- If the level sensor is not reached, the **Zephyr OEM** resumes normal operation.

If there is foam, the **Zephyr OEM** displays the code **W05** (see "**12.1 ZEPHYR OEM ALARMS TABLE**" ON PAGE 61).

9.8 Operating hours

The **Zephyr OEM** records the hours of humidifier operation to allow periodic maintenance.

The following times are monitored:

- Total hours of machine operating; this cannot be reset and shows the hours of humidifier operation;
- Partial hours of hydraulic unit operation; this can be reset after maintenance on the tank;
- Total hours of hydraulic unit operation; this can be reset after replacing the tank;
- Operating hours of the inlet solenoid valve; this can be reset after replacing the component;
- Operating hours of the inlet pump; this can be reset after replacing the component.

The configuration parameters for the maintenance warning thresholds are:

| Par. | Description | MU | Range |
|------------|---|------|-------------|
| M10 | Operating hours threshold for unit maintenance warning. | hx10 | 100....1000 |
| M11 | Partial operating hours threshold for the hydraulic unit maintenance warning. | hx10 | 100....1000 |
| M12 | Total operating hours threshold for the hydraulic unit maintenance warning. | hx10 | 100....1000 |
| M13 | Operating hours threshold for valve maintenance warning. | hx10 | 100....1000 |
| M14 | Operating hours threshold for the outlet pump maintenance warning. | hx10 | 100....1000 |

9.8.1 Resetting the operating hours

The operating hours can be reset from the maintenance menu by setting the parameters to 0.

9.9 Overproduction

When the humidity production exceeds 30% of the steam demand, draining is performed to return the steam production to the required value.

10. CONFIGURATION PARAMETERS

Description of columns in the Table of Parameters

- **Par.:** list of configurable device parameters;
- **Description:** indicates parameter operation and any possible selections;
- **MU:** measurement unit relating to the parameter;
- **Range:** describes the interval of values that the parameter can assume. This can be correlated with other instrument parameters (indicated with the parameter code).
NOTE: if the actual value is outside the permitted limits for that parameter (for example, because other parameters defining the aforementioned limits have been altered), the value of the violated limit is displayed instead of the actual value;
- **Default:** indicates the pre-set factory configuration;
- **PW:** indicates the access level for the parameter:
 - **U** = User parameters;
 - **M** = Maintenance parameters.

9.10 Table of adjustment parameters

| Par. | Description | MU | Range | Default | PW |
|----------------------------|--|-------|---|---------|----|
| SETPOINT group | | | | | |
| SP1 | Humidity setpoint. | % | r1...r2 | 70.0 | U |
| SP2 | Humidity limit setpoint. | % | r11...r12 | 85.0 | U |
| SP3 | Wellness temperature setpoint. | °C/°F | r21...r22 | 40.0 | U |
| CONFIGURATION group | | | | | |
| CFG | Operating mode (see " 9.2 HUMIDITY REGULATION" ON PAGE 44) 0-1 (0) = ON/OFF from digital input; PROP (1) = Proportional input; HUM (2) = Humidity sensor; HUML (3) = Humidity sensor + limit sensor; 1T (4) = 1 temperature sensor; 2T (5) = 2 temperature sensors. | --- | 0-1 / PROP / HUM / HUML / 1T / 2T | 0-1 | M |
| duAL | Dual boiler humidifier operation. 0 = Parallel; 1 = Sequential. | --- | 0/1 | 0 | U |
| P0 | Type of sensor S1 temperature of pre-heating + anti-freeze. --- (0) = Disabled; PTC (1) = PTC; NTC (2) = NTC. | --- | --- / PTC / NTC | --- | M |
| P1 | Electrical conductivity of the water. | µS/cm | 0...1250 | 0 | M |
| P2 | Type of regulator/sensor/probe S2 (regulation input). PTC (0) = PTC probe; 1000 (1) = Pt1000 probe; NTC (2) = NTC probe; 0-10 (3) = Proportional input 0...10 V; 0-5 (4) = Proportional input 0...5 V; 0.20 (5) = Input 0...20 mA; 4.20 (6) = Input 4...20 mA; E520 (7) = EVHTP520 proprietary probe. | --- | PTC / 1 000 / NTC / 0-10 / 0-5 / 0.20 / 4.20 / E520 | 0-10 | M |
| P3 | Minimum value of S2 (if CFG = HUM or CFG = HUML). | %rH | 0...100 | 0 | M |
| P4 | Maximum value of S2 (if CFG = HUM or CFG = HUML). | %rH | 0...100 | 100 | M |
| P5 | Offset of sensor S2 (if CFG = HUM or CFG = HUML). | %rH | -10...10 | 0 | M |
| P6 | Offset of sensor S1 (temperature). | °C/°F | -10.0...10.0 | 0.0 | M |
| P7 | Type of sensor/probe S3 (limit or averaging sensor with input P2 if temperature). Similar to P2 . | --- | PTC / 1 000 / NTC / 0-10 / 0-5 / 0.20 / 4.20 / E520 | 0-10 | M |
| P8 | Minimum value of S3 (if CFG = HUML). | %rH | 0...100 | 0 | M |
| P9 | Maximum value of S3 (if CFG = HUML). | %rH | 0...100 | 100 | M |
| P10 | Offset of sensor S3 humidity (if CFG = HUML). | %rH | -10...10 | 0 | M |
| P11 | TA sensor K (1000 = current multiplier of 1.000). | --- | 0...2000 | 1000 | M |
| P12 | Ventilation presence (enables maintenance management based on utility operating hours). No = No ventilation; Yes = Ventilation present. | --- | No/Yes | Yes | M |

| Par. | Description | MU | Range | Default | PW |
|---------------------------------|---|-------|--------------------|---------|----|
| P13 | Offset of sensor S2 temperature (of CFG = 1T or CFG = 2T). | °C/°F | -10.0...10.0 | 0.0 | M |
| P14 | Offset of sensor S3 temperature (of CFG = 1T or CFG = 2T). | °C/°F | -10.0...10.0 | 0.0 | M |
| P20 | Electrical conductivity of the water at 100°C (212 °F). 0 = 3000 µS/cm; 1 = 4000 µS/cm; 2 = 5000 µS/cm. | --- | 0...2 | 1 | M |
| P21 | Temperature unit of measure (changing value means that the temperature parameter limits will need to be reset manually). 0 = °C; 1 = °F. | --- | 0/1 | 0 | M |
| P22 | Steam production unit of measurement. 0 = kg/h; 1 = lb/h. | --- | 0/1 | 0 | M |
| REGULATION group | | | | | |
| r0 | Humidity probe setpoint hysteresis. | % | 0...20 | 2 | M |
| r1 | Minimum value for setting humidity setpoint. | % | 0... r2 | 20 | M |
| r2 | Maximum value for setting humidity setpoint. | % | r1 ...100 | 95 | M |
| r4 | Humidity proportional band. | % | 0...50 | 50 | M |
| r5 | Minimum production. | % | 20... r6 | 20 | M |
| r6 | Maximum production. | % | r5 ...100 | 75 | U |
| r10 | Humidity limit probe setpoint hysteresis. | % | 0...20 | 2 | M |
| r11 | Minimum value for setting humidity limit setpoint. | % | 0... r12 | 20 | M |
| r12 | Maximum limit setpoint value. | % | r11 ...100 | 95 | M |
| r20 | Temperature proportional band. | °C/°F | 0.1... 10.0 | 5.0 | M |
| r21 | Minimum value for setting temperature setpoint. | °C/°F | 10.0... r22 | 20.0 | M |
| r22 | Maximum value for setting temperature setpoint. | °C/°F | r21 ...60.0 | 50.0 | M |
| r23 | Wellness temperature probe 1 weight. | % | 0...100 | 50 | M |
| r24 | Wellness temperature probe 2 weight. | % | 0...100 | 50 | M |
| c0 | Number of consecutive days of inactivity after which the hydraulic unit is emptied. 0 = Function disabled. | days | 0...10 | 2 | M |
| c1 | Number of consecutive days of activity after which the hydraulic unit is emptied. 0 = Function disabled. | days | 0...100 | 14 | M |
| c3 | Type of draining for dilution. 0 = Current-based; 1 = Time-based. | --- | 0/1 | 0 | M |
| c4 | Draining duration for dilution (if c3 = 1). | s | 0...9999 | 5 | M |
| c5 | Time between two dilution draining events (if c3 = 1). | m | 30...999 | 60 | M |
| c6 | Percentage draining for dilution (if c3 = 0). | % | 20...80 | 30 | M |
| c10 | Maximum initial water filling time for water inlet check. | s | 50...2000 | 1200 | M |
| c11 | Anti-foam process. 0 = Disabled; 1 = Enabled. | --- | 0/1 | 0 | M |
| c14 | Time to drain the hydraulic unit completely. (*) Default according to model, from: 3 kg/h = 30 s; 5..15 kg/h = 40 s; 20...200 kg/h = 180 s. | s | 0...240 | (*) | M |
| c15 | Hours of dual hydraulic unit machine rotation. | hours | 10...500 | 150 | M |
| c16 | Low conductivity algorithm enable. 0 = Disabled; 1 = Enabled. | --- | 0/1 | 0 | M |
| MAINTENANCE/ALARMS group | | | | | |
| M5 | Low humidity alarm threshold. The hysteresis is fixed at 2%. 0 = Disabled. | % | 0...100 | 20 | M |
| M6 | High humidity alarm threshold. The hysteresis is fixed at 2%. 0 = Disabled. | % | 0...100 | 95 | M |
| M7 | High/low humidity alarm delay. 0 = Disabled. | s | 0...999 | 120 | M |
| M8 | Delay in alarm for no production | hours | 1...100 | 48 | M |
| M9 | Maximum number of automatic attempts to rearm alarm AL03 "No water" after which the alarm blocks manual rearming. | num | 1...10 | 3 | M |
| M10 | Operating hours threshold for unit maintenance warning. | hx10 | 100....10000 | 4000 | M |
| M11 | Partial operating hours threshold for the hydraulic unit maintenance warning. | hx10 | 100....2000 | 200 | M |
| M12 | Total operating hours threshold for the hydraulic unit maintenance warning. | hx10 | 100....2000 | 1000 | M |
| M13 | Operating hours threshold for valve maintenance warning. | hx10 | 100....2000 | 1000 | M |
| M14 | Operating hours threshold for pump maintenance warning. | hx10 | 100....2000 | 1000 | M |
| M15 | Operating hours threshold for fan maintenance warning. | hx10 | 100....2000 | 1000 | M |

| Par. | Description | MU | Range | Default | PW |
|----------------------------|--|-------|------------|---------|----|
| M20 | High temperature alarm threshold. The hysteresis is fixed at 0.5 °C; 0 = Disabled. | °C/°F | 0.0...80.0 | 50.0 | M |
| M21 | Maximum number of automatic attempts to rearm the high temperature alarm after which the alarm blocks manual rearming (attempts every hour) | num | 1...10 | 3 | M |
| COMMUNICATION group | | | | | |
| LA1 | Modbus communication protocol address. | num | 1...247 | 247 | M |
| Lb1 | Modbus transmission speed (baud rate). 0 = 2400; 1 = 4800; 2 = 9600; 3 = 19200; 4 = 38400. | --- | 0...4 | 4 | E |
| LP1 | Modbus parity bit. 0 = None; 1 = Odd; 2 = Even. | --- | 0...2 | 2 | E |
| LS1 | Modbus stop bit. 0 = 1 stop bit; 1 = 2 stop bits. | --- | 0/1 | 0 | E |
| PASSWORD group | | | | | |
| PA1 | First level password. 0 = No password | --- | -99...999 | 0 | U |
| PA2 | Second level password. | --- | -99...999 | 824 | M |

11. MODBUS RTU FUNCTIONS AND RESOURCES

11.1 Introduction

Modbus RTU (Remote Terminal Unit) protocol is a means of communication which allows data exchange between a computer and programmable logic controllers.

This protocol is based on the exchange of messages between master-slave and client-server devices. Master devices can receive information from slaves and write to their registers, while slave devices cannot initiate any information transfer until they receive a request from the slave device.

Modbus communication is used in industrial automation systems (IAS) and in the construction of building management systems (BMS). Modbus protocol is widely utilised due to the fact it is easy to use, very reliable and has an open source code that can be used royalty-free on any application or device.

Modbus RTU is the most common application and uses CRC error detection and binary encoding.




Fig. 34. Diagram showing message exchange in a Modbus communication

The Modbus protocol establishes a Protocol Data Unit (PDU) that is independent from the communication layer below it, introducing some additional fields specified on the Application Data Unit (ADU) ("**FIG. 35. FRAMING OF A MESSAGE USING MODBUS PROTOCOL" ON PAGE 53**) to specific buses and networks.

Devices such as PLCs (Programmable Logic Controller), HMIs (Human Machine Interface), control panels, drivers, motion controllers, I/O devices, etc. can use Modbus to begin a remote procedure, and the protocol is often used to connect a supervising computer with a Remote Terminal Unit in a supervision, control and data acquisition (SCADA) system.




Fig. 35. Framing of a message using Modbus protocol

For further information relating to the Modbus protocol, visit the official Modbus website: www.modbus.org.

11.2 Modbus message structure

Modbus RTU protocol requires the message to start with a silent time interval of at least 3.5 character times. This feature is often implemented by executing a time interval of multiple of character times at the baud rate used in the network. The characters available for each field are in binary form.

A description of the structure of a Modbus RTU message is provided below.

| Start | Address | Function | Data | CRC | Stop |
|--|--|---|--|--|--|
| 3.5 x character time | 8 bit | 8 bit | (N x 8 bit) | 16 bit | 3.5 x character time |
| Time period in which data must not be exchanged over the communication bus, to allow the connected instruments to recognise the end of one message and the start of the next | Corresponds to the address for the device with which the master has established dialogue; this is a value between 1...247. The address 0 is reserved for the broadcast message sent to all slave devices | Code for the function to execute or which has been executed | Contains the data sent by the master or sent back by the slave as a response to a question | Allows the master and the slave to check whether any errors are present during communication, and if there are, to ignore the message received | Time period in which data must not be exchanged over the communication bus, to allow the connected instruments to recognise the end of one message and the start of the next |

11.3 Modbus functions and registers

The Modbus registers for the device are organised around the four types of basic data reference indicated above, and this type of data is further identified by the first number of the address.

11.3.1 Available Modbus commands and data areas

The commands implemented are as follows:

| Command | Description |
|----------------------|--------------------------|
| 03 (hex 0x03) | Resource reading command |
| 06 (hex 0x06) | Resource writing command |

11.4 Address configuration

The RS-485 communication serial port can be used to configure the device, the parameters, the statuses and the Modbus variables and to monitor device operation using Modbus protocol.

The device address in a Modbus message is set by parameter **LA1**.

The address **0** is only used for broadcast messages, recognised by all slaves. Slave devices do not respond to a broadcast message.

Serial line configuration parameters, which can be accessed via the user interface menu, are:

| Par. | Description | MU | Range | Default |
|------------|--|-----|---------|---------|
| LA1 | Modbus communication protocol address. | --- | 0...247 | 247 |
| Lb1 | Modbus transmission speed (baud rate). 0 = 2400; 1 = 4800; 2 = 9600; 3 = 19200; 4 = 38400. | --- | 0...4 | 4 |
| LP1 | Modbus parity bit. 0 = None 1 = Odd; 2 = Even. | --- | 0...2 | 2 |
| LS1 | Modbus stop bit. 0 = 1 stop bit; 1 = 2 stop bits. | --- | 0/1 | 0 |

The RS-485 RTU serial line has the following characteristics:

- RTU mode;
- Bit: 8 bit

11.5 Connections

For the entire system to work properly, including the RS-485 RTU serial line, observe the instructions provided in chapter "**6. ELECTRICAL CONNECTIONS**" **ON PAGE 27**.

In particular, take care to make the connections correctly, observing the instructions in section "**6.4 ELECTRICAL CONNECTIONS**" **ON PAGE 29**

11.6 Modbus table content

Table content description

The table below contains the information required to access the resources properly and directly.

There are two tables:

- The Modbus address table, which contains all the configuration parameters for the device and the corresponding Modbus addresses;
- Modbus resource table, which contains all the status (I/O) and alarm resources in the device memory.

Description of columns in the Table of addresses

- **Par.:** list of configurable device parameters;
- **Description:** indicates parameter operation and any possible selections;
- **MU:** measurement unit relating to the parameter;
- **Range:** describes the interval of values that the parameter can assume. This can be correlated with other instrument parameters (indicated with the parameter code).
NOTE: if the actual value is outside the permitted limits for that parameter (for example, because other parameters defining the aforementioned limits have been altered), the value of the violated limit is displayed instead of the actual value;
- **Val. Adr.:** Indicates the address of the Modbus register containing the resource you want to access;
- **R/W:** Indicates the option of reading or writing the resource:
 - **R:** The resource is read-only;
 - **W:** The resource is write-only;
 - **R/W:** The resource can be both read and written.
- **CPL:** When the fields indicates Y, the value read by the register needs to be converted because the value represents a number with a sign. In the other cases the value is always positive or zero.
- **DATA SIZE:** Indicates the size in data bits:
 - **DWORD** = 32 bit
 - **DOUBLE** = 32 bit with sign
 - **SHORT** = 16 bit with sign
 - **WORD** = 16 bit
 - **Byte** = 8 bit
 - The "n" bits = 0...15 bit depending on the value of "n"

11.7 Modbus addresses

11.7.1 Modbus address table

| Par. | Description | Val. Adr. | R/W | DATA SIZE | CPL | MU | Range |
|----------------------------|--|-----------|-----|-----------|-----|-------|--------------|
| SETPOINT group | | | | | | | |
| SP1 | Humidity setpoint. | 2001 | R/W | SHORT | Y | % | r1...r2 |
| SP2 | Humidity limit setpoint. | 2002 | R/W | SHORT | Y | % | r11...r12 |
| SP3 | Temperature probe setpoint. | 2086 | R/W | SHORT | Y | °C/°F | r21...r22 |
| CONFIGURATION group | | | | | | | |
| CFG | Control input selection. 0-1 (0) = ON/OFF from digital input; PROP (1) = Proportional input; HUM (2) = Humidity sensor; HUML (3) = Humidity sensor + limit sensor; 1T (4) = 1 temperature sensor; 2T (5) = 2 temperature sensors. | 2003 | R/W | BYTES | --- | --- | 0...5 |
| duAL | Dual boiler humidifier operation. 0 = Parallel; 1 = Sequential. | 2066 | R/W | 1 BIT | --- | --- | 0/1 |
| nTyp | Master/Slave operation. 0 = Disabled; 1 = Parallel; 2 = Rotation; 3 = Balancing. | 2073 | R/W | BYTES | --- | --- | 0...3 |
| nAdr | Networked master/slave module (only if enabled Master/Slave Operation nTyp ≠ 0). 1 = Master; 2 = Slave 1; 3 = Slave 2; 4 = Slave 3; 5 = Slave 4. | 2070 | R/W | BYTES | --- | --- | 1...5 |
| nPrE | Master/Slave machine pre-heating enabled. 0 = Disabled; 1 = Enabled. | 2074 | R/W | 1BIT | --- | --- | 0/1 |
| ntot | Total number of Master/Slave machines. | 2072 | R/W | 3 BIT | --- | num | 2...5 |
| nbAc | Number of Master/Slave backup machines. | 2071 | R/W | 2BIT | --- | num | 1...3 |
| nHrs | Hours of Master/Slave machine rotation. | 2075 | R/W | BYTES | --- | hours | 10...500 |
| P0 | S1 sensor type (temperature). --- (0) = Disabled; PTC (1) = PTC; NTC (2) = NTC. | 2076 | R/W | 3 BIT | --- | --- | 0...2 |
| P1 | Electrical conductivity of the water. | 2006 | R/W | WORD | --- | µS/cm | 0...1250 |
| P2 | S2 sensor type (humidity 1 / proportional input). PTC (0) = PTC probe; 1000 (1) = Pt1000 probe; NTC (2) = NTC probe; 0-10 (3) = Proportional input 0...10 V; 0-5 (4) = Proportional input 0...5 V; 0.20 (5) = Input 0...20 mA; 4.20 (6) = Input 4...20 mA; E520 (7) = EVHTP520 proprietary probe. | 2007 | R/W | BYTES | --- | --- | 0...7 |
| P3 | Minimum value of S2 (if CFG = HUM or CFG = HUML). | 2008 | R/W | BYTES | --- | %rH | 0...100 |
| P4 | Maximum value of S2 (if CFG = HUM or CFG = HUML). | 2009 | R/W | BYTES | --- | %rH | 0...100 |
| P5 | Offset of sensor S2 (if CFG = HUM or CFG = HUML). | 2010 | R/W | BYTES | Y | %rH | -10...10 |
| P6 | Offset of sensor S1 (temperature). | 2011 | R/W | SHORT | Y | °C/°F | -10.0...10.0 |
| P7 | S3 sensor type (humidity 2 limit). Similar to P2 . | 2012 | R/W | BYTES | --- | --- | 0...7 |
| P8 | Minimum value of S3 (if CFG = HUML). | 2013 | R/W | BYTES | --- | %rH | 0...100 |
| P9 | Maximum value of S3 (if CFG = HUML). | 2014 | R/W | BYTES | --- | %rH | 0...100 |
| P10 | Offset of sensor S3 (if CFG = HUML). | 2015 | R/W | SHORT | Y | %rH | -10...10 |
| P12 | Ventilation presence (enables maintenance management based on utility operating hours). | 2077 | R/W | 1 BIT | --- | --- | 0/1 |

| Par. | Description | Val. Adr. | R/W | DATA SIZE | CPL | MU | Range |
|---------------------------------|---|------------------|-----|-----------|-----|--------------|-------------------|
| P13 | Offset of sensor S2 temperature (of CFG = 1T or CFG = 2T). | 2078 | R/W | SHORT | Y | °C/°F | -10.0...10.0 |
| P14 | Offset of sensor S3 temperature (of CFG = 1T or CFG = 2T). | 2079 | R/W | SHORT | Y | °C/°F | -10.0...10.0 |
| P20 | Electrical conductivity of the water at 100°C (212°F). 0 = 3000 µS/cm; 1 = 4000 µS/cm; 2 = 5000 µS/cm. | 2016 | R/W | 3 BIT | --- | --- | 0...2 |
| P21 | Temperature unit of measure (changing value means that the temperature parameter limits will need to be reset manually). 0 = °C; 1 = °F. | 2017 | R/W | 1 BIT | --- | --- | 0/1 |
| P22 | Steam production unit of measurement. 0 = kg/h; 1 = lb/h. | 2080 | R/W | 1 BIT | --- | --- | 0/1 |
| REGULATION group | | | | | | | |
| r0 | Sensor 1 setpoint hysteresis. | 2018 | R/W | BYTES | --- | % | 0...20 |
| r1 | Minimum setpoint value. | 2019 | R/W | BYTES | --- | % | 0... r2 |
| r2 | Maximum setpoint value. | 2020 | R/W | BYTES | --- | % | r1 ...100 |
| r4 | Proportional band. | 2021 | R/W | BYTES | --- | % | 0...50 |
| r5 | Minimum production. | 1927 | R/W | BYTES | --- | % | 0... r6 |
| r6 | Maximum production. | 1926 | R/W | BYTES | --- | % | r5 ...100 |
| r10 | Limit sensor setpoint hysteresis. | 2024 | R/W | BYTES | --- | % | 0...20 |
| r11 | Minimum limit setpoint value. | 2025 | R/W | BYTES | --- | % | 0... r12 |
| r12 | Maximum limit setpoint value. | 2026 | R/W | BYTES | --- | % | r11 ...100 |
| c0 | Number of continuous days of inactivity after which the boiler is emptied. 0 = Function disabled. | 2027 | R/W | BYTES | --- | days | 0...10 |
| c1 | Number of continuous days of activity after which the boiler is emptied. 0 = Function disabled. | 2028 | R/W | BYTES | --- | days | 0...100 |
| c2 | Number of cleaning cycles (filling+draining) following emptying due to activity or inactivity. | 2029 | R/W | BYTES | --- | num | 0...10 |
| c3 | Type of draining for dilution. 0 = Current-based; 1 = Time-based. | 2030 | R/W | 1 BIT | --- | --- | 0/1 |
| c4 | Draining duration for dilution (if C3 = 1). | 2031 | R/W | WORD | --- | s | 0...9999 |
| c5 | Time between two dilution draining events (if C3 = 1). | 2032 | R/W | WORD | --- | min | 30...999 |
| c6 | Draining value for dilution (if C3 = 0). | 2033 | R/W | BYTES | --- | % | 20...80 |
| c10 | Maximum initial water filling time for water inlet check, depending on the model. | 2036 | R/W | WORD | --- | s | 50...2000 |
| c11 | Anti-foam process. 0 = Disabled; 1 = Enabled. | 2037 | R/W | 1 BIT | --- | --- | 0/1 |
| c12 | Time to detect foam after lowering the current by 30%. | 2038 | R/W | WORD | --- | s | 10...300 |
| c13 | Enable water filling with steam generation active. | 2039 | R/W | 1 BIT | --- | --- | 0/1 |
| c14 | Time to drain the hydraulic unit completely. | 2040 | R/W | BYTES | --- | s | 0...240 |
| c15 | Hours of dual hydraulic unit machine rotation. | 2065 | R/W | WORD | --- | hours | 10...500 |
| c16 | Low conductivity algorithm enable. | 1323 | R/W | 1 BIT | --- | --- | 0/1 |
| MAINTENANCE/ALARMS group | | | | | | | |
| M5 | Low humidity alarm threshold. The hysteresis is fixed at 2%. 0 = Disabled. | 2041 | R/W | BYTES | --- | % | 0...100 |
| M6 | High humidity alarm threshold. The hysteresis is fixed at 2%. 0 = Disabled. | 2042 | R/W | BYTES | --- | % | 0...100 |
| M7 | High/low humidity alarm delay. 0 = Disabled. | 2043 | R/W | WORD | --- | s | 0...999 |
| M8 | Delay in alarm for no production. | 2064 | R/W | BYTES | --- | h | 1...100 |
| M9 | Maximum number of automatic attempts to rearm alarm AL03 "No water" after which the alarm blocks manual rearming | 2067 | R/W | BYTES | --- | num | 1...10 |
| M10 | Operating hours threshold for unit maintenance warning. | 2044 ... 2045 | R/W | DWORD | --- | hours x10 | 100....10000 |
| M11 | Operating hours threshold for partial boiler maintenance warning. | 2046 ... 2047 | R/W | DWORD | --- | hours x10 | 100....2000 |
| M12 | Operating hours threshold for full boiler maintenance warning. | 2048 ... 2049 | R/W | DWORD | --- | hours x10 | 100....2000 |

| Par. | Description | Val. Adr. | R/W | DATA SIZE | CPL | MU | Range |
|----------------------------|--|------------------|-----|-----------|-----|--------------|-------------|
| M13 | Operating hours threshold for valve maintenance warning. | 2050 ... 2051 | R/W | DWORD | --- | hours x10 | 100....2000 |
| M14 | Operating hours threshold for pump maintenance warning. | 2052 ... 2053 | R/W | DWORD | --- | hours x10 | 100....2000 |
| M15 | Operating hours threshold for fan maintenance warning. | 2054 ... 2055 | R/W | DWORD | --- | hours x10 | 100....2000 |
| M20 | High temperature alarm threshold. The hysteresis is fixed at 3 °C (6 °F); 0 = Disabled. | 2068 | R/W | BYTES | --- | °C/°F | 0.0...80.0 |
| M21 | Maximum number of automatic attempts to rearm the high temperature alarm after which the alarm blocks manual rearming (attempts every hour) | 2069 | R/W | BYTES | --- | num | 1...10 |
| COMMUNICATION group | | | | | | | |
| LA1 | Modbus communication protocol address. | 2056 | R/W | BYTES | --- | num | 1...247 |
| Lb1 | Modbus transmission speed (baud rate). 0 = 2400; 1 = 4800; 2 = 9600; 3 = 19200; 4 = 38400. | 2057 | R/W | BYTES | --- | --- | 0...4 |
| LP1 | Modbus parity bit. 0 = None; 1 = Odd; 2 = Even. | 2058 | R/W | BYTES | --- | --- | 0...2 |
| LS1 | Modbus stop bit. 0 = 1 stop bit; 1 = 2 stop bits. | 2059 | R/W | 1 BIT | --- | --- | 0/1 |
| PASSWORD group | | | | | | | |
| PA1 | First level password. 0 = No password. | 2061 | R/W | SHORT | Y | --- | -99...999 |
| PA2 | Second level password. | 2062 | R/W | SHORT | Y | --- | -99...999 |

11.7.2 Modbus resource table

| Code | Description | Val. Adr. | Filter value | R/W | DATA SIZE | CPL | MU | Range |
|-----------------------|--|-----------|--------------|-----|-----------|-----|-------|----------------------|
| DI1_s0 | Digital input S0 status. | 257 | --- | R | 1 BIT | --- | --- | 0/1 |
| DI2_cv | Digital input CV status. | 258 | --- | R | 1 BIT | --- | --- | 0/1 |
| DI3_of | Digital input 0/1 status. | 259 | --- | R | 1 BIT | --- | --- | 0/1 |
| DI4_ls | Level sensor input status. | 260 | --- | R | 1 BIT | --- | --- | 0/1 |
| DO1_EV1 | Inlet solenoid valve output status. | 385 | --- | R | 1 BIT | --- | --- | 0/1 |
| DO2_DP1 | Inlet pump output status. | 386 | --- | R | 1 BIT | --- | --- | 0/1 |
| DO3_G1 | Steam generation output status. | 387 | --- | R | 1 BIT | --- | --- | 0/1 |
| DO4_DEH | Dehumidification output status. | 388 | --- | R | 1 BIT | --- | --- | 0/1 |
| DO5_FANS | Ventilated distributor output status. | 389 | --- | R | 1 BIT | --- | --- | 0/1 |
| DO6_AL | Alarm output status. | 390 | --- | R | 1 BIT | --- | --- | 0/1 |
| AI_temperature | Temperature sensor S1 value. | 516 | --- | R | SHORT | Y | °C/°F | -3276.8... 3276.7 |
| AI_Humidity | Humidity sensor S2 value. | 517 | --- | R | SHORT | Y | %rH | -32768... 32767 |
| AI_Humidity_L | Humidity limit sensor S3 value. | 518 | --- | R | SHORT | Y | %rH | -32768... 32767 |
| AI_Request | Proportional input S2 value. | 519 | --- | R | SHORT | Y | % | -32768... 32767 |
| AI_Current | Current sensor CT1 value. | 520 | --- | R | SHORT | Y | A | -327.68... 327.67 |
| PackedAlarm1 | Status of warning W01 . | 769 | 0 | R | 1 BIT | --- | --- | 0/1 |
| PackedAlarm1 | Status of alarm AL01 . | 769 | 1 | R | 1 BIT | --- | --- | 0/1 |
| PackedAlarm1 | Status of warning W02 . | 769 | 2 | R | 1 BIT | --- | --- | 0/1 |
| PackedAlarm1 | Status of alarm AL02 . | 769 | 3 | R | 1 BIT | --- | --- | 0/1 |
| PackedAlarm1 | Status of alarm AL03 . | 769 | 4 | R | 1 BIT | --- | --- | 0/1 |
| PackedAlarm1 | Status of warning W04 . | 769 | 5 | R | 1 BIT | --- | --- | 0/1 |
| PackedAlarm1 | Status of warning W05 . | 769 | 6 | R | 1 BIT | --- | --- | 0/1 |
| PackedAlarm1 | Status of warning W06 . | 769 | 7 | R | 1 BIT | --- | --- | 0/1 |
| PackedAlarm1 | Status of alarm AL07 . | 769 | 8 | R | 1 BIT | --- | --- | 0/1 |
| PackedAlarm1 | Status of warning W08 . | 769 | 9 | R | 1 BIT | --- | --- | 0/1 |
| PackedAlarm1 | Status of alarm AL08 . | 769 | 10 | R | 1 BIT | --- | --- | 0/1 |
| PackedAlarm1 | Status of alarm AL09 . | 769 | 11 | R | 1 BIT | --- | --- | 0/1 |
| PackedAlarm1 | Status of alarm AL10 . | 769 | 12 | R | 1 BIT | --- | --- | 0/1 |
| PackedAlarm1 | Status of alarm AL11 . | 769 | 13 | R | 1 BIT | --- | --- | 0/1 |
| PackedAlarm1 | Status of warning W12 . | 769 | 14 | R | 1 BIT | --- | --- | 0/1 |
| PackedAlarm1 | Status of warning W13 . | 769 | 15 | R | 1 BIT | --- | --- | 0/1 |
| PackedAlarm2 | Status of alarm AL14 . | 770 | 0 | R | 1 BIT | --- | --- | 0/1 |
| PackedAlarm2 | Status of alarm AL15 . | 770 | 1 | R | 1 BIT | --- | --- | 0/1 |
| PackedAlarm2 | Status of alarm AL16 . | 770 | 2 | R | 1 BIT | --- | --- | 0/1 |
| PackedAlarm2 | Status of alarm AL17 . | 770 | 3 | R | 1 BIT | --- | --- | 0/1 |
| PackedAlarm2 | Status of alarm AL18 . | 770 | 4 | R | 1 BIT | --- | --- | 0/1 |
| PackedAlarm2 | Status of alarm AL19 . | 770 | 5 | R | 1 BIT | --- | --- | 0/1 |
| PackedAlarm2 | Status of alarm AL20 . | 770 | 6 | R | 1 BIT | --- | --- | 0/1 |
| PackedAlarm2 | Status of alarm AL21 . | 770 | 7 | R | 1 BIT | --- | --- | 0/1 |
| PackedAlarm2 | Status of alarm AL22 . | 770 | 8 | R | 1 BIT | --- | --- | 0/1 |
| PackedAlarm2 | Status of alarm AL23 . | 770 | 9 | R | 1 BIT | --- | --- | 0/1 |
| PackedAlarm2 | Status of alarm AL24 . | 770 | 10 | R | 1 BIT | --- | --- | 0/1 |
| PackedAlarm2 | Status of alarm AL25 . | 770 | 11 | R | 1 BIT | --- | --- | 0/1 |
| PackedAlarm2 | Status of alarm AL26 . | 770 | 12 | R | 1 BIT | --- | --- | 0/1 |
| PackedAlarm2 | Status of alarm AL27 . | 770 | 13 | R | 1 BIT | --- | --- | 0/1 |
| PackedAlarm2 | Status of alarm AL28 . | 770 | 14 | R | 1 BIT | --- | --- | 0/1 |
| PackedAlarm2 | Status of warning W29 . | 770 | 15 | R | 1 BIT | --- | --- | 0/1 |


| Code | Description | Val. Adr. | Filter value | R/W | DATA SIZE | CPL | MU | Range |
|---------------------|--|-----------|--------------|-----|-----------|-----|--------|------------------------|
| PackedAlarm3 | Status of alarm AL29 . | 771 | 0 | R | 1 BIT | --- | --- | 0/1 |
| PackedAlarm3 | Status of warning W30 . | 771 | 1 | R | 1 BIT | --- | --- | 0/1 |
| PackedAlarm3 | Status of alarm AL30 . | 771 | 2 | R | 1 BIT | --- | --- | 0/1 |
| PackedAlarm3 | Status of alarm AL31 . | 771 | 3 | R | 1 BIT | --- | --- | 0/1 |
| PackedAlarm3 | Status of warning W32 . | 771 | 4 | R | 1 BIT | --- | --- | 0/1 |
| PackedAlarm3 | Status of warning W33 . | 771 | 5 | R | 1 BIT | --- | --- | 0/1 |
| PackedAlarm3 | Status of warning W34 . | 771 | 6 | R | 1 BIT | --- | --- | 0/1 |
| PackedAlarm3 | Status of warning W35 . | 771 | 7 | R | 1 BIT | --- | --- | 0/1 |
| PackedAlarm3 | Status of alarm AL35 . | 771 | 8 | R | 1 BIT | --- | --- | 0/1 |
| PackedAlarm3 | Status of alarm AL36 . | 771 | 9 | R | 1 BIT | --- | --- | 0/1 |
| PackedAlarm3 | Status of alarm AL37 . | 771 | 10 | R | 1 BIT | --- | --- | 0/1 |
| PackedAlarm3 | Status of alarm AL38 . | 771 | 11 | R | 1 BIT | --- | --- | 0/1 |
| BMS_AL1 | AL01 manual reset. | 773 | --- | R/W | 1 BIT | --- | --- | 0/1 |
| BMS_AL3 | AL03 manual reset. | 774 | --- | R/W | 1 BIT | --- | --- | 0/1 |
| BMS_W04 | W04 manual reset. | 775 | --- | R/W | 1 BIT | --- | --- | 0/1 |
| BMS_AL22 | AL22 manual reset. | 776 | --- | R/W | 1 BIT | --- | --- | 0/1 |
| BMS_AL29_B2 | AL29 manual reset. | 777 | --- | R/W | 1 BIT | --- | --- | 0/1 |
| BMS_AL31_B2 | AL31 manual reset. | 778 | --- | R/W | 1 BIT | --- | --- | 0/1 |
| BMS_W32_B2 | W32 manual reset. | 779 | --- | R/W | 1 BIT | --- | --- | 0/1 |
| manWash | Manual draining command (OFF/ON). | 1282 | --- | R/W | 1 BIT | --- | --- | 0/1 |
| GeneralAlarm | General alarm status (OFF/ON). | 1283 | --- | R/W | 1 BIT | --- | --- | 0/1 |
| unitOn | Unit status (OFF/ON). | 1284 | --- | R/W | 1 BIT | --- | --- | 0/1 |
| --- | Restore default parameters command | 1285 | --- | R/W | 1 BIT | --- | --- | 0/1 |
| HoursService | Hours of humidifier operation (LOW) (*). | 1286 | --- | R/W | DWORD | --- | h x 10 | 0.0 ... 429496729.5 |
| | Hours of humidifier operation (HIGH) (*). | 1287 | --- | R/W | DWORD | --- | h x 10 | 0.0 ... 429496729.5 |
| HoursBoilerP | Partial hours of boiler operation. (LOW) (*). | 1288 | --- | R/W | DWORD | --- | h x 10 | 0.0 ... 429496729.5 |
| | Partial hours of boiler operation. (HIGH) (*). | 1289 | --- | R/W | DWORD | --- | h x 10 | 0.0 ... 429496729.5 |
| HoursBoilerT | Total hours of boiler operation (hours x 10) (LOW) (*). | 1290 | --- | R/W | DWORD | --- | h x 10 | 0.0 ... 429496729.5 |
| | Total hours of boiler operation (hours x 10). (HIGH) (*). | 1291 | --- | R/W | DWORD | --- | h x 10 | 0.0 ... 429496729.5 |
| HoursEV1 | Hours of water inlet solenoid valve operation (hours x 10) (LOW) (*). | 1292 | --- | R/W | DWORD | --- | h x 10 | 0.0 ... 429496729.5 |
| | Hours of water inlet solenoid valve operation (hours x 10) (HIGH) (*). | 1293 | --- | R/W | DWORD | --- | h x 10 | 0.0 ... 429496729.5 |
| HoursPump | Hours of outlet pump operation (hours x 10) (LOW) (*). | 1294 | --- | R/W | DWORD | --- | h x 10 | 0.0 ... 429496729.5 |
| | Hours of outlet pump operation (hours x 10). (HIGH) (*). | 1295 | --- | R/W | DWORD | --- | h x 10 | 0.0 ... 429496729.5 |
| HoursFan | Hours of fan operation (hours x 10) (LOW) (*). | 1296 | --- | R/W | DWORD | --- | h x 10 | 0.0 ... 429496729.5 |
| | Hours of fan operation (hours x 10). (HIGH) (*). | 1297 | --- | R/W | DWORD | --- | h x 10 | 0.0 ... 429496729.5 |
| curr100 | Nominal current. | 1298 | --- | R/W | WORD | --- | A | 0.00...655.35 |
| tevap | Evaporation time. | 1299 | --- | R/W | WORD | --- | s | 0.0 ... 6553.5 |
| actProd | Actual steam production. | 1303 | --- | R/W | SHORT | Y | kg/h | -3276.8 ... 3276.7 |
| limH | Humidity limit sensor status (ON/OFF). | 1304 | --- | R/W | 1 BIT | --- | --- | 0/1 |

| Code | Description | Val. Adr. | Filter value | R/W | DATA SIZE | CPL | MU | Range |
|--------------------|---|-----------|--------------|-----|-----------|-----|--------|------------------------|
| HoursAct | Hours of continuous activity. (LOW) (*). | 1316 | --- | R/W | DWORD | --- | h x 10 | 0.0 ... 429496729.5 |
| | Hours of continuous activity. (HIGH) (*). | 1317 | --- | R/W | DWORD | --- | h x 10 | 0.0 ... 429496729.5 |
| HoursNotAct | Hours of continuous inactivity. (LOW) (*). | 1318 | --- | R/W | DWORD | --- | h x 10 | 0.0 ... 429496729.5 |
| | Hours of continuous inactivity. (HIGH) (*). | 1319 | --- | R/W | DWORD | --- | h x 10 | 0.0 ... 429496729.5 |
| MBS_SwEn | On/Off command from BMS. | 1922 | --- | R/W | 1 BIT | --- | --- | 0/1 |

(*) **Calculation of operating hours**

Operating hours = (HIGH register x 65536) + LOW register

12. DIAGNOSTICS

The table below lists alarms with corresponding solutions. Indication takes place via the alarm LED  and the buzzer. Each alarm is recorded in the alarm log.

12.1 Zephyr OEM alarms table

| Code | Description | Cause | Effects | Solution |
|-------------|---|--|--|---|
| W01 | Warning: +30% overcurrent | <ul style="list-style-type: none"> Overcurrent between the electrodes Electrodes not working or shorted | <ul style="list-style-type: none"> Fixed alarm icon W01 displayed Partial draining W01 recorded in the log | <ul style="list-style-type: none"> Carry out maintenance Replace the boiler Check that the outlet pump is working |
| AL01 | Alarm: +50% overcurrent | <ul style="list-style-type: none"> Current sensor not working Control board not working Boiler compromised High electrical conductivity Use softened water | <ul style="list-style-type: none"> Fixed alarm icon AL01 displayed Humidifier OFF AL01 recorded in the log | <ul style="list-style-type: none"> Check that the TA is working (if external) Check the water properties |
| W02 | Warning: no production | <ul style="list-style-type: none"> Foam in the boiler Water inlet flow rate too low Boiler failing Water pipes or filter clogged | <ul style="list-style-type: none"> Fixed alarm icon W02 displayed No effect on regulation W02 recorded in the log | <ul style="list-style-type: none"> Check the water mains flow rate Check that the solenoid valve is working Carry out maintenance on the solenoid valve |
| AL02 | Alarm: no production | <ul style="list-style-type: none"> Backpressure at the steam outlet is greater than rated value Very low electrical conductivity No production for a long time | <ul style="list-style-type: none"> Fixed alarm icon AL02 displayed Alarm relay ON Humidifier OFF if AL02 > 100 h AL02 recorded in the log | <ul style="list-style-type: none"> Replace the solenoid valve Check for foam Check the backpressure in the steam outlet duct |
| AL03 | Alarm: no water | <ul style="list-style-type: none"> Water fill time > c10 Inlet filter clogged Solenoid valve not working Water pressure too low Water inlet circuit leaking | <ul style="list-style-type: none"> Fixed alarm icon AL03 displayed Humidifier inhibited for 15 minutes AL03 recorded in the log | <ul style="list-style-type: none"> Check the water mains flow rate Check that the solenoid valve is working Carry out maintenance on the solenoid valve Replace the solenoid valve Check and clean the internal pipes and inlet/outlet manifold Cleaning the boiler Replace the boiler (if there is significant limescale residue) |
| W04 | Warning: insufficient draining | <ul style="list-style-type: none"> Insufficient water drained Water inlet/outlet clogged | <ul style="list-style-type: none"> Fixed alarm icon W04 displayed Alarm relay ON W04 recorded in the log | <ul style="list-style-type: none"> Cleaning the boiler Replace the boiler (if there is significant limescale residue) Clean the pump, outlet manifold and outlet circuit Replace the outlet pump if it is not working |
| W05 | Warning: foam | The water in the boiler reaches the maximum level sensor | <ul style="list-style-type: none"> Fixed alarm icon W05 displayed Anti-foam washing activated W05 recorded in the log | <ul style="list-style-type: none"> Automatic reset If it persists over time, disconnect the humidifier water connections and let the water drain, then wash and clean the boiler Check if the filling water is softened |
| W06 | Warning: suspected high electrical conductivity | <ul style="list-style-type: none"> High current Low filling frequency | <ul style="list-style-type: none"> Fixed alarm icon W06 displayed Automatic washing activated W06 recorded in the log | <ul style="list-style-type: none"> Carry out maintenance Check the inlet water properties |
| AL07 | Alarm: machine service life | Hours of unit operation > M10 | <ul style="list-style-type: none"> Fixed alarm icon AL07 displayed Alarm relay ON AL07 recorded in the log | Carry out full maintenance |

| Code | Description | Cause | Effects | Solution |
|-------------|-------------------------------------|---|--|--|
| W08 | Warning: boiler maintenance | Hours of boiler operation > M11 | <ul style="list-style-type: none"> Fixed alarm icon W08 displayed Alarm relay ON W08 recorded in the log | Clean the boiler |
| AL08 | Alarm: boiler service life | Hours of boiler operation > M12 | <ul style="list-style-type: none"> Fixed alarm icon AL08 displayed Alarm relay ON Humidifier OFF AL08 recorded in the log | Replace the boiler |
| AL09 | Alarm: solenoid valve maintenance | Hours of solenoid valve operation > M13 | <ul style="list-style-type: none"> Fixed alarm icon AL09 displayed No effect on regulation AL09 recorded in the log | <ul style="list-style-type: none"> Clean the water inlet filter Check for leaks Replace the inlet solenoid valve if necessary Reset the counter |
| AL10 | Alarm: pump maintenance | Hours of pump operation > M14 | <ul style="list-style-type: none"> Fixed alarm icon AL10 displayed No effect on regulation AL10 recorded in the log | <ul style="list-style-type: none"> Clean the pump and the inlet and outlet manifold Clean the inlet/outlet circuit Check for leaks Replace the outlet pump if necessary Reset the counter |
| AL11 | Alarm: fan maintenance | Hours of fan operation > M15 | <ul style="list-style-type: none"> Fixed alarm icon AL11 displayed No effect on regulation AL11 recorded in the log | <ul style="list-style-type: none"> Clean the fans and grilles Remove residues and dust incrustations Replace any fans that are not working Reset the counter |
| W12 | Warning: low humidity | Humidity production < M5 for a time > M7 | <ul style="list-style-type: none"> Fixed alarm icon W12 displayed Alarm relay ON W12 recorded in the log | <ul style="list-style-type: none"> If it occurs together with other alarms, check accordingly If the humidifier is underdimensioned, contact the system designer Check R6 and set it > 70% |
| W13 | Warning: high humidity | Humidity production > M6 for a time > M7 | <ul style="list-style-type: none"> Fixed alarm icon W13 displayed Alarm relay ON W13 recorded in the log | <ul style="list-style-type: none"> If it occurs together with other alarms, check accordingly If the humidifier is overdimensioned, contact the system designer Check R6 and set it < 70% |
| AL14 | Alarm: temperature sensor S1 | <ul style="list-style-type: none"> Probe not working Probe not connected properly Incorrect probe type | <ul style="list-style-type: none"> Fixed alarm icon AL14 displayed Humidifier OFF AL14 recorded in the log | <ul style="list-style-type: none"> Check the sensor type Check the sensor wiring Change the sensor type Check for electrical noise |

| Code | Description | Cause | Effects | Solution |
|-------------|---|--|--|--|
| AL15 | Alarm: humidity sensor S2 | <ul style="list-style-type: none"> • Sensor not working • Sensor not connected correctly • Control board not working | <ul style="list-style-type: none"> • Fixed alarm icon • AL15 displayed • Alarm relay ON • Humidifier OFF • AL15 recorded in the log | <ul style="list-style-type: none"> • Check the sensor type (P2) • Check the sensor wiring • Change the sensor type • Check for electrical noise |
| AL16 | Alarm: humidity limit sensor S3 | | <ul style="list-style-type: none"> • Fixed alarm icon • AL16 displayed • Alarm relay ON • Humidifier OFF • AL16 recorded in the log | <ul style="list-style-type: none"> • Check the sensor type (P7) • Check the sensor wiring • Change the sensor type • Check for electrical noise |
| AL17 | Alarm: proportional request from regulator | | <ul style="list-style-type: none"> • Fixed alarm icon • AL17 displayed • Alarm relay ON • Humidifier OFF • AL17 recorded in the log | <ul style="list-style-type: none"> • Check the regulator wiring • Check the regulator type |
| AL18 | Alarm: current sensor CT | | <ul style="list-style-type: none"> • Fixed alarm icon • AL18 displayed • Alarm relay ON • Humidifier OFF • AL18 recorded in the log | <ul style="list-style-type: none"> • Check for water leaks • Check the electrical phase wiring on the boiler and contactor • Check that the TA is working • If the control board or current sensor are not working, replace the control board |
| AL19 | Alarm: temperature sensor 1 | <ul style="list-style-type: none"> • Probe not working • Probe not connected properly • Incorrect probe type | <ul style="list-style-type: none"> • Fixed alarm icon • AL19 displayed • Alarm relay ON • Humidifier OFF • AL19 recorded in the log | <ul style="list-style-type: none"> • Check the sensor type • Check the sensor wiring • Change the sensor type • Check for electrical noise |
| AL20 | Alarm: temperature sensor 2 | | <ul style="list-style-type: none"> • Fixed alarm icon • AL20 displayed • Alarm relay ON • Humidifier OFF • AL20 recorded in the log | |
| AL21 | Alarm: hydraulic unit 2 current sensor | <ul style="list-style-type: none"> • Phase via sensor disconnected • Control board not working • Current sensor not working • Inlet solenoid valve not working • Possible water leakage | <ul style="list-style-type: none"> • Fixed alarm icon • AL21 displayed • Alarm relay ON • Humidifier OFF • AL21 recorded in the log | <ul style="list-style-type: none"> • Check for water leaks • Check the electrical phase wiring on the hydraulic unit and contactor • Check that TA 2 is working • If the control board or current sensor are not working, replace the control board |
| AL22 | Alarm: high temperature in wellness room | Wellness room temperature > M20 | <ul style="list-style-type: none"> • Fixed alarm icon • AL22 displayed • Alarm relay ON • Humidifier OFF • AL22 recorded in the log | <ul style="list-style-type: none"> • Wait until room temperature < M20 - 3 °C • Check and eliminate the cause of wellness room temperature > M20 |
| AL23 | Alarm: hydraulic unit 2 expansion board offline | No communication between control board and expansion device | <ul style="list-style-type: none"> • AL23 displayed • Alarm relay ON • All regulators for the second boiler are switched off • AL23 recorded in the log | <ul style="list-style-type: none"> • Restore communication between control board and expansion device • Automatic reset |
| AL24 | Alarm master offline (only on slave) | No communication between slave humidifier and master humidifier when nTyP ≠ 0 | <ul style="list-style-type: none"> • AL24 displayed • Alarm relay ON • All regulators related to the Master humidifier are switched off (slaves operate as stand-alone) • AL24 recorded in the log | <ul style="list-style-type: none"> • Restore communication between slave humidifier and master humidifier • Automatic reset |

| Code | Description | Cause | Effects | Solution |
|-------------|--|--|--|--|
| AL25 | Alarm: slave 1 offline or alarmed (only on master) | <ul style="list-style-type: none"> No communication between master humidifier and slave 1 humidifier when nTyP ≠ 0 Slave 1 alarmed with regulation block | <ul style="list-style-type: none"> AL25 displayed Alarm relay ON Slave 1 OFF, other humidifiers operate normally AL25 recorded in the log | <ul style="list-style-type: none"> Restore communication between master humidifier and slave 1 humidifier Automatic reset |
| AL26 | Alarm: slave 2 offline or alarmed (only on master) | <ul style="list-style-type: none"> No communication between master humidifier and slave 2 humidifier when nTyP ≠ 0 Slave 2 alarmed with regulation block | <ul style="list-style-type: none"> AL26 displayed Alarm relay ON Slave 2 OFF, other humidifiers operate normally AL26 recorded in the log | <ul style="list-style-type: none"> Restore communication between master humidifier and slave 2 humidifier Automatic reset |
| AL27 | Alarm: slave 3 offline or alarmed (only on master) | <ul style="list-style-type: none"> No communication between master humidifier and slave 3 humidifier when nTyP ≠ 0 Slave 3 alarmed with regulation block | <ul style="list-style-type: none"> AL27 displayed Alarm relay ON Slave 3 OFF, other humidifiers operate normally AL27 recorded in the log | <ul style="list-style-type: none"> Restore communication between master humidifier and slave 3 humidifier Automatic reset |
| AL28 | Alarm: slave 4 offline or alarmed (only on master) | <ul style="list-style-type: none"> No communication between master humidifier and slave 4 humidifier when nTyP ≠ 0 Slave 3 alarmed with regulation block | <ul style="list-style-type: none"> AL28 displayed Alarm relay ON Slave 4 OFF, other humidifiers operate normally AL28 recorded in the log | <ul style="list-style-type: none"> Restore communication between master humidifier and slave 4 humidifier Automatic reset |
| W29 | Warning: +30% overcurrent in hydraulic unit 2 | <ul style="list-style-type: none"> Overcurrent between the electrodes Electrodes not working or shorted Current sensor not working | <ul style="list-style-type: none"> Fixed alarm icon W29 displayed Partial draining W29 recorded in the log | <ul style="list-style-type: none"> Carry out maintenance Replace hydraulic unit 2 Check that the outlet pump for hydraulic unit 2 is working Check that the TA is working (if external) Check the water properties |
| AL29 | Alarm: +50% overcurrent in hydraulic unit 2 | <ul style="list-style-type: none"> Control board not working Boiler compromised High electrical conductivity Use softened water | <ul style="list-style-type: none"> Fixed alarm icon AL29 displayed Humidifier OFF AL29 recorded in the log | |
| W30 | Warning: no production from hydraulic unit 2 | <ul style="list-style-type: none"> Foam in hydraulic unit 2 Water inlet flow rate too low Hydraulic unit 2 failing | <ul style="list-style-type: none"> Fixed alarm icon W30 displayed No effect on regulation W30 recorded in the log | <ul style="list-style-type: none"> Check the water mains flow rate Check that the solenoid valve is working in hydraulic unit 2 Carry out maintenance on the solenoid valve in hydraulic unit 2 Replace the solenoid valve Check for foam Check the backpressure in the steam outlet duct |
| AL30 | Alarm: no production from hydraulic unit 2 | <ul style="list-style-type: none"> Water pipes or filter clogged Backpressure at the steam outlet is greater than rated value Very low electrical conductivity No production for a long time | <ul style="list-style-type: none"> Fixed alarm icon AL30 displayed Alarm relay ON Humidifier OFF if AL30 > 100 h AL30 recorded in the log | |
| AL31 | Alarm: no water in hydraulic unit 2 | <ul style="list-style-type: none"> Water fill time > c10 Inlet filter clogged Solenoid valve not working Water pressure too low Water inlet circuit leaking | <ul style="list-style-type: none"> Fixed alarm icon AL31 displayed Humidifier inhibited for 15 minutes AL31 recorded in the log | <ul style="list-style-type: none"> Check the water mains flow rate Check that the solenoid valve is working in hydraulic unit 2 Carry out maintenance on the solenoid valve in hydraulic unit 2 Replace the solenoid valve Check and clean the internal pipes and inlet/outlet manifold Clean hydraulic unit 2 Replace hydraulic unit 2 (if there is significant limescale residue) |
| W32 | Warning: insufficient draining from hydraulic unit 2 | <ul style="list-style-type: none"> Insufficient water drained Water inlet/outlet clogged | <ul style="list-style-type: none"> Fixed alarm icon W32 displayed Alarm relay ON W32 recorded in the log | <ul style="list-style-type: none"> Clean hydraulic unit 2 Replace hydraulic unit 2 (if there is significant limescale residue) Clean the pump, outlet manifold and outlet circuit Replace the outlet pump if it is not working |

| Code | Description | Cause | Effects | Solution |
|-------------|---|---|--|--|
| W33 | Warning: foam in hydraulic unit 2 | The water in hydraulic unit 2 reaches the maximum level sensor | <ul style="list-style-type: none"> • Fixed alarm icon • W33 displayed • Anti-foam washing activated • W33 recorded in the log | <ul style="list-style-type: none"> • Automatic reset • If it persists over time, disconnect the humidifier water connections and let the water drain, then wash and clean the boiler • Check if the filling water is softened |
| W34 | Warning: suspected high electrical conductivity in hydraulic unit 2 | <ul style="list-style-type: none"> • High current • Low filling frequency | <ul style="list-style-type: none"> • Fixed alarm icon • W34 displayed • Automatic washing activated • W34 recorded in the log | <ul style="list-style-type: none"> • Carry out maintenance • Check the inlet water properties |
| W35 | Warning: hydraulic unit 2 maintenance | Hours of hydraulic unit 2 operation > M11 | <ul style="list-style-type: none"> • Fixed alarm icon • W35 displayed • Alarm relay ON • W35 recorded in the log | Clean the boiler |
| AL35 | Alarm: hydraulic unit 2 service life | Hours of hydraulic unit 2 operation > M12 | <ul style="list-style-type: none"> • Fixed alarm icon • AL35 displayed • Alarm relay ON • Humidifier OFF • AL35 recorded in the log | Replace boiler 2 |
| AL36 | Alarm: hydraulic unit 2 solenoid valve maintenance | Hours of hydraulic unit 2 solenoid valve operation > M13 | <ul style="list-style-type: none"> • Fixed alarm icon • AL36 displayed • No effect on regulation • AL36 recorded in the log | <ul style="list-style-type: none"> • Clean the water inlet filter • Check for leaks • Replace the inlet solenoid valve if necessary • Reset the counter |
| AL37 | Alarm: hydraulic unit 2 pump maintenance | Hours of hydraulic unit 2 pump operation > M14 | <ul style="list-style-type: none"> • Fixed alarm icon • AL37 displayed • No effect on regulation • AL37 recorded in the log | <ul style="list-style-type: none"> • Clean the pump and the inlet and outlet manifold • Clean the inlet/outlet circuit • Check for leaks • Replace the outlet pump if necessary • Reset the counter |

13. MAINTENANCE

13.1 Before you start

Zephyr OEM series humidifiers are defined as "NOT ACCESSIBLE TO THE PUBLIC".

DANGER

RISK OF ELECTRIC SHOCK, EXPLOSION OR ELECTRIC ARC

- Any procedure on the humidifier, including maintenance of any type, must only be carried out while the power supply is disconnected.
- The maintenance, repair, installation and use of the equipment must only be entrusted to qualified personnel.

WARNING

RISK OF BURNS

Before carrying out any work on the system, place the equipment out of service and wait for the machine to cool down (< 50 °C (122 °F)).

NOTE: The images in this document and other documentation supplied with the product are provided for illustrative purposes only and may differ from the product itself.

13.2 Introduction to maintenance

The boiler provided (equipped) requires frequent maintenance and seasonal cleaning in the following conditions:

| Electrical conductivity of the water | Water hardness |
|--------------------------------------|----------------|
| 75...600 µS/cm | 5...30 °f |

It is not possible to provide specific instructions to determine the maintenance frequency, as it depends heavily on the morphology of the water used, which can vary even with the same hardness and electrical conductivity.

When using Zephyr OEM series humidifiers with more critical water conditions (harder with high electrical conductivity), for example:

| Electrical conductivity of the water | Water hardness |
|--------------------------------------|----------------|
| 700...1250 µS/cm | 35...50 °f |

that lead to an increase in maintenance frequency (even weekly in extreme cases), a special range of boilers designed and developed to operate with hard water can be used (see "**1.6 ACCESSORIES**" ON PAGE 13).

Using the special boiler reduces the maintenance and cleaning frequency, but cannot be quantified solely from the electrical conductivity and hardness of the water.

NOTICE

MALFUNCTIONING OF THE EQUIPMENT

Only use the humidifier with the water specifications indicated in this manual.

If frequent boiler maintenance is required, check the quality of the water supply.

Moreover, replace the boiler promptly when:

- The drain water is very dark (reddish/black) and demonstrates the start of electrode corrosion caused by the highly aggressive nature of concentrated water and the associated electrical phenomena;
- The humidifier frequently drains the water completely to dilute it and perform a complete wash; Zephyr OEM series humidifiers normally renew the water in the boiler in a balanced way, optimising efficiency while reducing the risk of malfunction in relation to the amount of steam produced.
NOTE: A high concentration of salts in the water in the boiler results in high electrical conductivity, which can cause various high current alarms and lead to frequent draining cycles.
- The boiler has reached 5 seasons or 24 months of continuous operation with maintenance carried out in accordance with best practices or in any case at most 20000 hours;
- There are large amounts of limescale that lead to colour and surface variations on the outer walls of the boiler due to overheating caused by limescale bridging between the electrical phases;
NOTE: Limescale inside the boiler is normal, even in large amounts, as the boiler collects the limescale present in the water; therefore performing maintenance/cleaning on it is essential for correct operation.

NOTE: Since the boiler is a consumable item, it is not covered by warranty, unless problems are encountered during the initial start-up.

NOTICE

MALFUNCTIONING OF THE EQUIPMENT

Only carry out boiler maintenance in accordance with the instructions provided in the **Maintenance** chapter of this manual.

- There are leaks due to breakages, cracks and fissures.

NOTE: The water in the boiler is subjected to an electrical voltage and therefore leaks from the boiler are dangerous.

DANGER

RISK OF ELECTRIC SHOCK OR ELECTRIC ARC

- Any procedure on the humidifier, including maintenance of any type, must only be carried out while the power supply is disconnected.
- In the event of water leakage, disconnect the humidifier power supply immediately.

- If any adverse event not described in this documentation arises, carry out maintenance and/or replace the boiler. Plus, contact ELSTEAM customer service for the relevant guidelines and instructions;

DANGER

RISK OF ELECTRIC SHOCK, EXPLOSION OR ELECTRIC ARC

If an adverse event occurs, disconnect the humidifier power supply immediately.

- After a period of activity and/or due to the water properties, limescale formation inside the boiler may bring the electrodes closer together and/or closer to the boiler walls. This could potentially form a conducting path that may lead to a temperature increase when there is no water (causing the boiler surfaces to become black) and melt the boiler wall, allowing live water to leak out (replace the hydraulic unit);

DANGER

RISK OF ELECTRIC SHOCK OR ELECTRIC ARC

- In the event of water leakage, disconnect the humidifier power supply immediately.
- Check the boiler sealing gaskets and replace them if necessary

13.3 Checking the status of the humidifier

Perform the following scheduled checks on the humidifier:

| When... | What to do... |
|---------------------------|---|
| At first start-up | Make sure there are no leaks after an hour of continuous operation. |
| When replacing components | Make sure there are no leaks after an hour of continuous operation. |
| Every 7 days | <ul style="list-style-type: none">• Make sure the humidifier works properly (based on the instructions provided in this manual);• Make sure there are no leaks in the plumbing system;• Make sure there is no unusual operation. |
| Every 30 days | <ul style="list-style-type: none">• Make sure there are no blockages in the water drain;• Make sure the water drains effectively;• Remove any limescale residue from inside the drain. |
| Every 60 days | <ul style="list-style-type: none">• Make sure that the limescale build up in the boiler is not excessive;• Wash the inside of the boiler with a 20% concentration of citric acid, removing limescale from the electrodes and boiler.• If necessary, replace the electrodes and gaskets. |
| Every 3 years (*) | Replace the boiler. |
| Every 7 years (**) | Replace the boiler. |

(*) **NOTE:** If the humidifier is used continuously.

(**) **NOTE:** If the humidifier is used seasonally.

Inadequate use and/or poor maintenance of the humidifier can damage your health.

WARNING

BIOLOGICAL RISK

- In the event of poor maintenance/cleaning after the humidifier has been shut-down for a long time, microorganisms (including the bacteria that cause Legionellosis) may proliferate and be transferred into the air treatment system.
- The humidifier must be used correctly and be maintained and cleaned properly at the prescribed intervals, as described in the **MAINTENANCE** chapter.

Thoroughly remove limescale and biofilm residues from the reservoir and drain (rinse the inside of the reservoir with 20% citric acid and appropriate biocides, and clean the limescale off the surface).

13.4 Cleaning the boiler

- Drain the humidifier manually;
- Disconnect the machine power supply using the external isolator;
- Disconnect the electrode power cables and the signal cable of the high level sensor, which are connected at the top of the boiler (take care not to damage the amperometric transformer (TA) on the electronic board);
- Disconnect the steam delivery pipe from the top of the boiler;
- Release the boiler from the fastener holding it to the metal structure;
- Remove the boiler from the water supply and outlet manifolds;
- Undo the 4 screws in the coupling area between the top and bottom of the boiler;
- Clean any limescale residues from the boiler and its electrodes with a plastic scraper;
- Leave the boiler to soak in a citric acid solution for a few hours and then repeat the previous step;
- Wash the whole boiler in running water to flush away any material removed by hand;
- Carefully refit the central seal in position and close the boiler with the screws in the coupling area;
- Reassemble the boiler by following the removal procedure in reverse.
- Check that the electrodes are securely fastened to the boiler and make good electrical connections by securing the cable lugs in such a way that the wiring harness cannot become loose during normal humidifier operation.

⚠ ⚠ DANGER

LOOSE WIRING CAUSES ELECTRIC SHOCKS AND OVERHEATING

Tighten the connections in compliance with the technical specifications relating to tightening torques.




Fig. 36. Cleaning the boiler

13.5 Replacing the boiler

- Drain the humidifier manually;
- Disconnect the machine power supply using the external isolator;
- Disconnect the electrode power cables and the signal cable of the high level sensor, which are connected at the top of the boiler (take care not to damage the amperometric transformer (TA) on the electronic board);
- Disconnect the steam delivery pipe from the top of the boiler;
- Release the boiler from the fastener holding it to the metal structure;
- Remove the boiler from the water supply and outlet manifolds;
- Insert the new boiler as described in "**13.6 FITTING THE BOILER" ON PAGE 70**;
- Depending on the Zephyr humidifier you have, make sure that the cable connections are tightened properly (see "**6. ELECTRICAL CONNECTIONS" ON PAGE 27**);
- Check that the electrodes are securely fastened to the boiler and make good electrical connections (in accordance with the current regulations) by securing the cable lugs in such a way that the wiring harness cannot become loose during normal humidifier operation.

⚠ ⚠ DANGER

LOOSE WIRING CAUSES ELECTRIC SHOCKS AND OVERHEATING

Tighten the connections in compliance with the technical specifications relating to tightening torques.




Fig. 37. Replacing the boiler

13.5.1 Tightening torque for electrode connections

| Boiler | Nuts | Spanner | Tightening torque |
|--------------|------|---------|-------------------|
| 3...15 kg/h | M5 | SW8 | 2.5 Nm |
| 20...40 kg/h | M6 | SW10 | 4 Nm |

13.6 Fitting the boiler


- Insert the boiler into the outlet manifold and secure it with the Velcro strap to prevent it from falling off;
- Check that the electrodes are securely fastened to the boiler and make good electrical connections by securing the cable lugs in such a way that the wiring harness cannot become loose during normal humidifier operation.

  **DANGER**

LOOSE WIRING CAUSES ELECTRIC SHOCKS AND OVERHEATING

Tighten the connections in compliance with the technical specifications relating to tightening torques.

13.7 Cleaning/replacing the electrodes



14. SPARE PARTS

14.1 Hydraulic unit




Fig. 38. Spare parts for Zephyr OEM series - Plumbing Part

| Ref. | P/n | Description |
|-----------------|--------------------------------------|--|
| ① | EHKTOK01 | Inlet solenoid valve EHK008...EHK015 |
| | EHKTOK02 | Inlet solenoid valve EHK020...EHK040 |
| | EHKTOK03 | Inlet solenoid valve EHK002...EHK005 |
| ② | EHKTOK07 | Filling reservoir |
| ③ | EHKTOK09 | XS-S-M boiler seal kit |
| | EHKTOK10 | L boiler seal kit |
| ④ | EHKTOK21 | Electrode kit for EBK005M00M |
| | EHKTOK22 | Electrode kit for EBK005MHCM |
| | EHKTOK23 | Electrode kit for EBK005MLCM |
| | EHKTOK27 | Electrode kit for EBK002M00XS |
| | EHKTOK28 | Electrode kit for EBK002MHCXS |
| | EHKTOK29 | Electrode kit for EBK002MLCXS |
| | EHKTOK30 | Electrode kit for EBK015T00M |
| | EHKTOK31 | Electrode kit for EBK015THCM |
| | EHKTOK32 | Electrode kit for EBK015TLCM |
| | EHKTOK33 | Electrode kit for EBK040T00L/EBK050T00L |
| | EHKTOK34 | Electrode kit for EBK040THCL/EBK050THCL |
| | EHKTOK35 | Electrode kit for EBK040TLCL |
| | EHKTOK39 | Electrode kit for EBK003M00S |
| | EHKTOK40 | Electrode kit for EBK003MHCS |
| | EHKTOK41 | Electrode kit for EBK003MLCS |
| | EHKTOK42 | Electrode kit for EBK005T00S |
| | EHKTOK43 | Electrode kit for EBK005THCS |
| | EHKTOK44 | Electrode kit for EBK005TLCS |
| | EHKTOK45 | Electrode kit for EBK003T00XS |
| | EHKTOK46 | Electrode kit for EBK003THCXS |
| EHKTOK47 | Electrode kit for EBK003TLCXS | |

| Ref. | P/n | Description |
|-------------------|--|--|
| ⑤ | EHKTOK04 | Electric outlet pump |
| ⑥ | EHKTOK05 | Inlet/outlet manifold |
| ⑦ | EHKTOK06 | Outlet circuit kit |
| ⑧ | EBK002M00XS | Cleanable boiler for ExtraSmall standard, 2 kg/h, single-phase models |
| | EBK002MHCXS | Cleanable boiler for ExtraSmall high-conductivity, 2 kg/h, single-phase models |
| | EBK002MLCXS | Cleanable boiler for ExtraSmall low-conductivity, 2 kg/h, single-phase models |
| | EBK003M00S | Cleanable boiler for Small standard, 3 kg/h, single-phase models |
| | EBK003MHCS | Cleanable boiler for Small high-conductivity, 3 kg/h, single-phase models |
| | EBK003MLCS | Cleanable boiler for Small low-conductivity, 3 kg/h, single-phase models |
| | EBK003T00XS | Cleanable boiler for ExtraSmall standard, 3 kg/h, three-phase models |
| | EBK003THCXS | Cleanable boiler for ExtraSmall high-conductivity, 3 kg/h, three-phase models |
| | EBK003TLCXS | Cleanable boiler for ExtraSmall low-conductivity, 3 kg/h, three-phase models |
| | EBK005M00M | Cleanable boiler for Medium standard, 3–5 kg/h, single-phase models |
| | EBK005MHCM | Cleanable boiler for Medium high-conductivity, 3–5 kg/h, single-phase models |
| | EBK005MLCM | Cleanable boiler for Medium low-conductivity, 3–5 kg/h, single-phase models |
| | EBK005T00S | Cleanable boiler for Small standard, 5–8 kg/h, three-phase models |
| | EBK005THCS | Cleanable boiler for Small high-conductivity, 5–8 kg/h, three-phase models |
| | EBK005TLCS | Cleanable boiler for Small low-conductivity, 5–8 kg/h, three-phase models |
| | EBK015T00M | Cleanable boiler for standard, 10–15 kg/h, three-phase models |
| | EBK015THCM | Cleanable boiler for high-conductivity, 10–15 kg/h, three-phase models |
| | EBK015TLCM | Cleanable boiler for low-conductivity, 10–15 kg/h, three-phase models |
| | EBK040T00L | Cleanable boiler for standard, 20–30–40 kg/h, three-phase models |
| | EBK040THCL | Cleanable boiler for high-conductivity, 20–30–40 kg/h, three-phase models |
| EBK040TLCL | Cleanable boiler for low-conductivity, 20–30–40 kg/h, three-phase models | |

14.2 Electrical part




Fig. 39. Electrical spare parts for **Zephyr OEM**

| Ref. | P/n | Description |
|------|-------------------|-----------------------|
| ① | EHHKT011P4 | Complete control unit |

15.2 Wiring diagram for 400/460 Vac 3Ph models

The customer is responsible for connecting the transformer/contactor/fuse holder.




Fig. 41. Wiring diagram for models **EHK0003 / EHK0005 / EHK0010 / EHK0020**


16. SELECTING AND DEFINING THE MODEL

16.1 Introduction


The **Parameters Manager**, can be used to choose the desired humidifier model and configure the machine.

16.2 Procedure for selecting and defining the model

1. Run **Parameters Manager**;
2. Enter the **Parameters** sheet followed by the **Maintenance Parameters** section;




3. Enter the access password (32917) in the OEM Password field. The fields needed to access, select and define the model will then be displayed (wait 5 seconds to see them appear automatically);




These fields are:

- **CloneModeOEM**: allows the OEM user to enter the mode for selecting and defining the model;
- **Model To Write**: sets the code of the model to be entered;
- **Humidifier Model code**: Displays the p/n of the selected humidifier (read-only);
- **Humidifier Model production**: Displays the production capacity (in kg/h) of the selected humidifier (read-only);
- **Humidifier Model phases**: Displays the number of power supply phases for the selected humidifier (read-only);
- **Humidifier Model power supply**: Displays the power supply type for the selected humidifier (read-only);
- **Humidifier Model type**: Displays the selected humidifier series (read-only).

4. Set the **CloneModeOEM** field to 1; the board will enter the mode for selecting and defining the model.
NOTE: Some parameters may have abnormal values. Do not edit these values.




5. Set the **Model To Write** field to the numerical code of the desired model (8 in the example);




| Par. | Description | MU | Range | |
|-----------------------|---------------------------|-----|--------|---------------------------|
| Model To Write | Humidifier model. | --- | 0...60 | |
| | 0 = EHK0003M2 | | | 18...36 = Reserved |
| | 1 = EHK0003T2 | | | 37 = EHK0002M2 |
| | 2 = EHK0003T4 | | | 38 = EHK0003T5 |
| | 3 = EHK0005M2 | | | 39 = EHK0005T5 |
| | 4 = EHK0005T2 | | | 40 = EHK0010T5 |
| | 5 = EHK0005T4 | | | 41 = EHK0015T5 |
| | 6 = EHK0010T4 | | | 42 = EHK0020T5 |
| | 7 = EHK0010T2 | | | 43 = EHK0030T5 |
| | 8 = EHK0015T4 | | | 44 = EHK0040T5 |
| | 9 = EHK0015T2 | | | 45 = EHK0050T5 |
| | 10 = EHK0020T4 | | | 46...59 = Reserved |
| | 11 = EHK0020T2 | | | 60 = EHK0008T4 |
| | 12 = EHK0030T4 | | | |
| | 13 = EHK0040T4 | | | |
| | 14 = EHK0050T4 | | | |
| | 15...17 = Reserved | | | |

NOTE: Do not enter values marked as **RESERVED** in the table above.

6. Set the **CloneModeOEM** field to 0 to exit from the mode for selecting and defining the model;



7. The procedure takes a few seconds to complete. Please wait.
When the procedure is complete, the description of the configured model will appear in the **Humidifier Model** field.



8. Procedure finished.

This page has been left blank on purpose.



This document and the solutions contained within it are the intellectual property of ELSTEAM, safeguarded by the Italian Industrial Property Code (CPI). ELSTEAM forbids the reproduction and distribution, even in part, of the contents, unless express authorisation is obtained directly from ELSTEAM.

The customer (manufacturer, installer or end user) assumes all responsibility for device configuration.

ELSTEAM does not assume any responsibility for potential errors and reserves the right to make any changes, at any time, without the basic functional and safety-related features being affected.

MADE IN ITALY

ELSTEAM S.r.l.

Via Enrico Fermi 496, 21042,
Caronno Pertusella (VA) ITALY

Telephone: +39 02 9659890

Fax: +39 02 96457007

Email: info@elsteam.it

Web: www.elsteam.com